



Service Manual

# Service Manual

Service Manual



## DIGITAL LASER PRINTER

### ML-331x/ML-371x Series

ML-331xD/331xND/371xD/371xND/371xDW

The keynote of Product

#### 1. Speed

- ML-331x series : 31 ppm in A4 / 33 ppm in Letter
- ML-371x series : 35 ppm in A4 / 37 ppm in Letter

#### 2. Processor

- ML-331x series : 375 MHz
- ML-371x series : 600 MHz

#### 3. Printer Languages

- ML-331x series : SPL, PCL5e
- ML-371x series : PCL6/5e, PostsScript3, IBM ProPrinter, EPSON

#### 4. Memory (Std / Max)

- ML-331x series : 64 MB / 64 MB
- ML-371xD : 64 MB / 320 MB
- ML-371xND/371xDW : 128 MB / 384 MB

#### 5. Interfaces

- High Speed USB 2.0
- 10/100 BaseTX network connector (ML-331xND)
- 10/100/1000 BaseTX network connector (ML-371xND/371xDW)
- 802.11b/g/n wireless LAN (ML-371xDW)
- IEEE 1284 Parallel (Optional)

#### 6. Toner Cartridge (Initial / Sales)

- ML-331x series : 2K / 2K, 5K
- ML-371x series : 5K / 2K, 5K, 10K



**ELECTRONICS**

# *Service Manual*

GSPN (Global Service Partner Network)

North America : [service.samsungportal.com](http://service.samsungportal.com)

Latin America : [latin.samsungportal.com](http://latin.samsungportal.com)

CIS : [cis.samsungportal.com](http://cis.samsungportal.com)

Europe : [europe.samsungportal.com](http://europe.samsungportal.com)

China : [china.samsungportal.com](http://china.samsungportal.com)

Asia : [asia.samsungportal.com](http://asia.samsungportal.com)

Mideast & Africa : [mea.samsungportal.com](http://mea.samsungportal.com)

© Samsung Electronics Co.,Ltd. September. 2010  
Printed in Korea.

**VERSION NO. : 1.00    CODE : 3310-00000E**

## *chapter 1* *Precautions*

1.1 Safety Warning .....	1-1
1.2 Caution for safety .....	1-2
1.2.1 Toxic material.....	1-2
1.2.2 Electric Shock and Fire Safety Precautions .....	1-2
1.2.3 Handling Precautions .....	1-3
1.2.4 Assembly / Disassembly Precautions .....	1-3
1.2.5 Disregarding this warning may cause bodily injury .....	1-4
1.3 ESD Precautions .....	1-5

## *chapter 2* *Product specifications and descriptions*

2.1 Specifications .....	2-1
2.1.1 Product Overview .....	2-1
2.1.2 Features by models .....	2-2
2.1.3 Specifications.....	2-3
2.1.4 Model Comparison Table .....	2-10
2.2 Product Description .....	2-11
2.2.1 Front View .....	2-11
2.2.2 Rear View .....	2-12
2.2.3 Paper Path .....	2-13
2.2.4 System layout .....	2-14
2.2.5 Hardware configuration .....	2-21
2.2.6 Engine F/W Control Algorithm.....	2-39
2.2.7 S/W Descriptions .....	2-42

## *chapter 3* *Disassembly and Reassembly*

3.1 General precautions on disassembly .....	3-1
3.2 Screws used in the printer .....	3-2

3.3 Disassembly procedure .....	3-3
3.3.1 Cover .....	3-3
3.3.2 Main board .....	3-6
3.3.3 HVPS board .....	3-6
3.3.4 SMPS board .....	3-7
3.3.5 Laser Scanning Unit (LSU) .....	3-7
3.3.6 Fuser unit .....	3-8
3.3.7 Main drive unit .....	3-9
3.3.8 Feed drive unit .....	3-10
3.3.9 Pick up/ Regi/ MP clutch .....	3-10
3.3.10 Pick up roller .....	3-11
3.3.11 Transfer roller .....	3-11
3.3.12 MP unit .....	3-12
3.3.13 OPE board .....	3-13
3.3.14 Bin-full sensor .....	3-13
3.3.15 Regi. / Feed / Empty sensor .....	3-14
3.3.16 Cassette roller (Retard roller) .....	3-15

## *chapter 4 Alignment and Troubleshooting*

4.1 Alignment and Adjustments.....	4-1
4.1.1 Control Panel.....	4-1
4.1.2 Understanding The Status LED .....	4-4
4.1.3 JAM Removal .....	4-5
4.1.4 Useful menu item for service .....	4-9
4.1.5 Periodic Defective Image.....	4-11
4.1.6 Using the Easy Printer Manager program and smart panel ...	4-12
4.1.7 Updating Firmware .....	4-14
4.1.8 Tech Mode .....	4-17
4.2 Troubleshooting.....	4-22
4.2.1 Procedure of Checking the Symptoms .....	4-22
4.2.2 Error Message and Troubleshooting .....	4-25
4.2.3 Image Quality problem .....	4-41
4.2.4 Other errors .....	4-25
4.2.5 Network problems .....	4-41



## *chapter 5* *System Diagram*

5.1 Block Diagram .....	5-1
5.2 Connection Diagram.....	5-3

## *chapter 6* *Reference Information*

6.1 Tool for Troubleshooting .....	6-1
6.2 Acronyms and Abbreviations .....	6-2
6.2.1 Acronyms .....	6-2
6.2.2 Service Parts .....	6-4
6.3 A4 ISO 19752 Standard Pattern.....	6-8
6.3.1 A4 ISO 19752 Standard Pattern .....	6-8
6.4 Selecting a location .....	6-9

## *attached* *Parts Catalog (Exploded Views & Parts List)*

# 1. Precautions

In order to prevent accidents and to prevent damage to the equipment please read the precautions listed below carefully before servicing the printer and follow them closely.

## 1.1 Safety Warning

- (1) Only to be serviced by appropriately qualified service engineers.  
High voltages and lasers inside this product are dangerous. This printer should only be serviced by a suitably trained and qualified service engineer.
- (2) Use only Samsung replacement parts  
There are no user serviceable parts inside the printer. Do not make any unauthorized changes or additions to the printer, these could cause the printer to malfunction and create electric shock or fire hazards.
- (3) Laser Safety Statement  
The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, chapter 1 Subchapter J for Class I(1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 60825-1:1993 + A1:1997 + A2:2001. Class I laser products are not considered to be hazardous. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance or prescribed service condition.
  - Wavelength: 800 nm
  - Beam divergence
    - Parallel: 12 degrees
    - Perpendicular: 35 degrees
  - Maximum power or energy output: 15 mW

### WARNING

*Never operate or service the printer with the protective cover removed from Laser/Scanner assembly. The reflected beam, although invisible, can damage your eyes. When using this product, these basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to persons:*

	CAUTION - CLASS 3B LASER RADIATION WHEN OPEN AVOID EXPOSURE TO THE BEAM.
	DANGER - LASER RADIATION AVOID DIRECT EXPOSURE TO BEAM.
	DANGER - RADIATIONS INVISIBLES DU LASER EN CAS D'OUVERTURE. EVITER TOUTE EXPOSITION DIRECTE AU FAISCEAU.
	VORSICHT - UNSICHTBARE LASERSTRAHLUNG, WENN ABDECKUNG GEÖFFNET. NICHT DEM STRAHL AUSSETZEN.
	ATTENZIONE - RADIAZIONE LASER INVISIBILE IN CASO DI APERTURA. EVITARE L'ESPOSIZIONE AL FASCIO.
	PRECAUCIÓN - RADIACIÓN LASER INVISIBLE CUANDO SE ABRE. EVITAR EXPONERSE AL RAYO.
	PERIGO - RADIAÇÃO LASER INVISÍVEL AO ABRIR. EVITE EXPOSIÇÃO DIRECTA AO FEIXE.
	GEVAAR - ONZICHTBARE LASERSTRALEN BIJ GEOPENDE KLEP. DEZE KLEP NIET OPENEN.
	ADVARSEL - USYNLIG LASERSTRÅLNING VED ÅBNING. UNDGÅ UDSAETTELSE FOR STRÅLNING.
	ADVARSEL - USYNLIG LASERSTRÅLNING NÅR DEKSEL ÅPNES. UNNGÅ EKSPONERING FOR STRÅLEN.
VARNING - OSYNLIG LASERSTRÅLNING NÅR DENNA DEL ÄR ÖPPEN. STRÅLEN ÄR FARLIG.	
VAROITUS - NÄKYMÄTÖNTÄ LASERSÄTEILYÄ AVATTAESSA. VARO SUORAA ALTISTUMISTA SÄTEELLE.	
<b>注意</b> 严禁揭开此盖, 以免激光泄露灼伤 주의 이 덮개를 열면 레이저광에 노출될 수 있으므로 주의하십시오.	

## 1.2 Caution for safety

### 1.2.1 Toxic material

This product contains toxic materials that could cause illness if ingested.

- (1) If the LCD control panel is damaged it is possible for the liquid inside to leak. This liquid is toxic. Contact with the skin should be avoided, wash any splashes from eyes or skin immediately and contact your doctor. If the liquid gets into the mouth or is swallowed see a doctor immediately.
- (2) Please keep Drum cartridge and Toner Cartridge away from children. The toner powder contained in the Drum cartridge and Toner Cartridge may be harmful and if swallowed you should contact a doctor.

### 1.2.2 Electric Shock and Fire Safety Precautions

Failure to follow the following instructions could cause electric shock or potentially cause a fire.

- (1) Use only the correct voltage, failure to do so could damage the printer and potentially cause a fire or electric shock.
- (2) Use only the power cable supplied with the printer. Use of an incorrectly specified cable could cause the cable to overheat and potentially cause a fire.
- (3) Do not overload the power socket, this could lead to overheating of the cables inside the wall and could lead to a fire.
- (4) Do not allow water or other liquids to spill into the printer, this can cause electric shock. Do not allow paper clips, pins or other foreign objects to fall into the printer these could cause a short circuit leading to an electric shock or fire hazard.
- (5) Never touch the plugs on either end of the power cable with wet hands, this can cause electric shock. When servicing the printer remove the power plug from the wall socket.
- (6) Use caution when inserting or removing the power connector. The power connector must be inserted completely otherwise a poor contact could cause overheating possibly leading to a fire. When removing the power connector grip it firmly and pull.
- (7) Take care of the power cable. Do not allow it to become twisted, bent sharply round corners or otherwise damaged. Do not place objects on top of the power cable. If the power cable is damaged it could overheat and cause a fire or exposed cables could cause an electric shock. Replace a damaged power cable immediately, do not reuse or repair the damaged cable. Some chemicals can attack the coating on the power cable, weakening the cover or exposing cables causing fire and shock risks.
- (8) Ensure that the power sockets and plugs are not cracked or broken in any way. Any such defects should be repaired immediately. Take care not to cut or damage the power cable or plugs when moving the machine.
- (9) Use caution during thunder or lightening storms. Samsung recommend that this machine be disconnected from the power source when such weather conditions are expected. Do not touch the machine or the power cord if it is still connected to the wall socket in these weather conditions.
- (10) Avoid damp or dusty areas, install the printer in a clean well ventilated location. Do not position the machine near a humidifier. Damp and dust build up inside the machine can lead to overheating and cause a fire.
- (11) Do not position the printer in direct sunlight. This will cause the temperature inside the printer to rise possibly leading to the printer failing to work properly and in extreme conditions could lead to a fire.
- (12) Do not insert any metal objects into the machine through the ventilator fan or other part of the casing, it could make contact with a high voltage conductor inside the machine and cause an electric shock.

## 1.2.3 Handling Precautions

The following instructions are for your own personal safety, to avoid injury and so as not to damage the printer

- (1) Ensure the printer is installed on a level surface, capable of supporting its weight. Failure to do so could cause the printer to tip or fall.
- (2) The printer contains many rollers, gears and fans. Take great care to ensure that you do not catch your fingers, hair or clothing in any of these rotating devices.
- (3) Do not place any small metal objects, containers of water, chemicals or other liquids close to the printer which if spilled could get into the machine and cause damage or a shock or fire hazard.
- (4) Do not install the machine in areas with high dust or moisture levels, beside an open window or close to a humidifier or heater. Damage could be caused to the printer in such areas.
- (5) Do not place candles, burning cigarettes, etc on the printer, These could cause a fire.

## 1.2.4 Assembly / Disassembly Precautions

Replace parts carefully, always use Samsung parts. Take care to note the exact location of parts and also cable routing before dismantling any part of the machine. Ensure all parts and cables are replaced correctly. Please carry out the following procedures before dismantling the printer or replacing any parts.

- (1) Check the contents of the machine memory and make a note of any user settings. These will be erased if the mainboard or network card is replaced.
- (2) Ensure that power is disconnected before servicing or replacing any electrical parts.
- (3) Disconnect printer interface cables and power cables.
- (4) Only use approved spare parts. Ensure that part number, product name, any voltage, current or temperature rating are correct.
- (5) When removing or re-fitting any parts do not use excessive force, especially when fitting screws into plastic.
- (6) Take care not to drop any small parts into the machine.
- (7) Handling of the OPC Drum
  - The OPC Drum can be irreparably damaged if it is exposed to light. Take care not to expose the OPC Drum either to direct sunlight or to fluorescent or incandescent room lighting. Exposure for as little as 5 mins can damage the surface's photoconductive properties and will result in print quality degradation. Take extra care when servicing the printer. Remove the OPC Drum and store it in a black bag or other lightproof container. Take care when working with the covers (especially the top cover) open as light is admitted to the OPC area and can damage the OPC Drum.
  - Take care not to scratch the green surface of the OPC Drum Unit. If the green surface of the Drum Cartridge is scratched or touched the print quality will be compromised.

### **1.2.5 Disregarding this warning may cause bodily injury**

- (1) Be careful with the high temperature part.  
The fuser unit works at a high temperature. Use caution when working on the printer. Wait for the fuser to cool down before disassembly.
- (2) Do not put finger or hair into the rotating parts.  
When operating a printer, do not put hand or hair into the rotating parts (Paper feeding entrance, motor, fan, etc.). If do, you can get harm.
- (3) When you move the printer.  
This printer weighs 9kg (19.84 lbs) including toner cartridge and cassette. Use safe lifting and handling techniques. Use the lifting handles located on each side of the machine. Back injury could be caused if you do not lift carefully.
- (4) Ensure the printer is installed safely.  
The printer weighs 9kg (19.84 lbs), ensure the printer is installed on a level surface, capable of supporting its weight. Failure to do so could cause the printer to tip or fall possibly causing personal injury or damaging the printer.
- (5) Do not install the printer on a sloping or unstable surface. After installation, double check that the printer is stable.

## 1.3 ESD Precautions

Certain semiconductor devices can be easily damaged by static electricity. Such components are commonly called “Electrostatically Sensitive (ES) Devices” or ESDs. Examples of typical ESDs are: integrated circuits, some field effect transistors, and semiconductor “chip” components. The techniques outlined below should be followed to help reduce the incidence of component damage caused by static electricity.

*Caution >>Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.*

1. Immediately before handling a semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, employ a commercially available wrist strap device, which should be removed for your personal safety reasons prior to applying power to the unit under test.
2. After removing an electrical assembly equipped with ESDs, place the assembly on a conductive surface, such as aluminum or copper foil, or conductive foam, to prevent electrostatic charge buildup in the vicinity of the assembly.
3. Use only a grounded tip soldering iron to solder or desolder ESDs.
4. Use only an “anti-static” solder removal device. Some solder removal devices not classified as “anti-static” can generate electrical charges sufficient to damage ESDs.
5. Do not use Freon-propelled chemicals. When sprayed, these can generate electrical charges sufficient to damage ESDs.
6. Do not remove a replacement ESD from its protective packaging until immediately before installing it. Most replacement ESDs are packaged with all leads shorted together by conductive foam, aluminum foil, or a comparable conductive material.
7. Immediately before removing the protective shorting material from the leads of a replacement ESD, touch the protective material to the chassis or circuit assembly into which the device will be installed.
8. Maintain continuous electrical contact between the ESD and the assembly into which it will be installed, until completely plugged or soldered into the circuit.
9. Minimize bodily motions when handling unpackaged replacement ESDs. Normal motions, such as the brushing together of clothing fabric and lifting one’s foot from a carpeted floor, can generate static electricity sufficient to damage an ESD.

## 2. Product specifications and descriptions

### 2.1 Specifications

#### 2.1.1 Product Overview



1. Speed

- ML-331x series : 31 ppm in A4 / 33 ppm in Letter
- ML-371x series : 35 ppm in A4 / 37 ppm in Letter

2. Processor

- ML-331x series : 375 MHz
- ML-371x series : 600 MHz

3. Printer Languages

- ML-331x series : SPL, PCL5e
- ML-371x series : PCL6/5e, PostsScript3, IBM ProPrinter, EPSON

4. Memory (Std / Max)

- ML-331x series : 64 MB / 64 MB
- ML-371xD : 64 MB / 320 MB
- ML-371xND/371xDW : 128 MB / 384 MB

5. Interfaces

- High Speed USB 2.0
- 10/100 BaseTX network connector (ML-331xND)
- 10/100/1000 BaseTX network connector (ML-371xND/371xDW)
- 802.11b/g/n wireless LAN (ML-371xDW)
- IEEE 1284 Parallel (Optional)

6. Toner cartridge (Initial / Sales)

- ML-3310 series : 2K / 2K, 5K
- ML-3710 series : 5K / 2K, 5K, 10K

## 2. Product specifications and descriptions

## 2.1.2 Features by models

Features	ML-3310D ML-3312D	ML-3310ND ML-3312D	ML-3710D ML-3712D	ML-3710ND ML-3712ND	ML-3710DW ML-3712DW
Hi-Speed USB 2.0	●	●	●	●	●
IEEE 1284 Parallel	○	○	○	○	○
Network Interface Ethernet 10/100 Base TX wired LAN		●			
Network Interface Ethernet 10/100/1000 Base TX wired LAN				●	●
Network Interface 802.11b/g/n wireless LAN					●
IPv6		●		●	●
Eco printing	●	●	●	●	●
Wi-Fi Protected Setup (WPS)					●
Duplex (2-sided) printing	●	●	●	●	●
Samsung Easy Printer Driver Manager	●	●	●	●	●
Memory			○	○	○
Tray 2		○	○	○	○
SyncThru Web Service		●		●	●

( ●: Included, ○: Optional, Blank: Not available)



## 2. Product specifications and descriptions

## 2.1.3 Specifications

- Product Specifications are subject to change without notice. See below for product specifications.

## 2.1.3.1 General Print Engine

Item		ML-331x series	ML-371x series
Engine Speed	Simplex	Up to 31 ppm in A4 (33 ppm in Letter)	Up to 35 ppm in A4 (37 ppm in Letter)
	Duplex	Up to 15 ipm in A4 (16 ipm in Letter)	Up to 17 ipm in A4 (18 ipm in Letter)
Warmup time	From Sleep	15 sec	15 sec
FPOT	From Ready	As fast as 8 sec	As fast as 8 sec
	From Sleep	As fast as 15.5 sec	As fast as 15.5 sec
Resolution	-	Up to 1,200 x 1,200 dpi effective output	Up to 1,200 x 1,200 dpi effective output

## 2.1.3.2 Controller &amp; S/W

Item		ML-331x series	ML-371x series
Processor		Samsung 375 MHz	Samsung 600 MHz
Memory	Std.	64 MB	- 371xD : 64 MB - 371xND / 371xDW : 128 MB
	Max.	64 MB	- 371xD : 320 MB - 371xND / 371xDW : 384 MB
	Flash	- 331xD : 8 MB- 331xND : 16 MB	- 371xD : 16 MB - 371xND / 371xDW : 32 MB
Printer Languages		PCL5e, SPL IBM ProPrinter, EPSON	PostScript3, PCL6/5e, IBM ProPrinter, EPSON
Fonts		93 scalable, 1 bitmap	93 scalable, 1 bitmap, 136 PostScript3 fonts
Driver	Default Driver	SPL	PCL
	Install	SPL	PCL6 / PS3
	Supporting OS	Windows 2000/XP (32/64 bits) / Vista (32/64 bits) / 2003 Server (32/64 bits) / 2008 Server(32/64 bits) / 7 (32/64 bits) /2008 Server R2	Windows 2000/XP (32/64 bits) / Vista (32/64 bits) / 2003 Server (32/64 bits) / 2008 Server(32/64 bits) / 7 (32/64 bits) /2008 Server R2

## 2. Product specifications and descriptions

Item		ML-331x series	ML-371x series
Driver (Continue..)	Supporting OS (Continue..)	Various Linux OS: Fedora Core 4, 5, 6 Fedora 7, 8, 9, 10, 11, 12 RedHat Enterprise Linux WS 4, 5 SuSE 10.0, 10.1 openSuSE 10.2, 10.3, 11.0, 11.1, 11.2 SuSE Linux Enterprise Desktop 10, 11 Debian 4.0, 5.0 Ubuntu 5.04, 5.10, 6.04, 6.10, 7.04, 7.10, 8.04, 8.10, 9.04, 9.10 Mandriva 2005LE, 2006, 2007, 2007.1, 2008, 2008.1, 2009, 2009.1	Various Linux OS: Fedora Core 4, 5, 6 Fedora 7, 8, 9, 10, 11, 12 RedHat Enterprise Linux WS 4, 5 SuSE 10.0, 10.1 openSuSE 10.2, 10.3, 11.0, 11.1, 11.2 SuSE Linux Enterprise Desktop 10, 11 Debian 4.0, 5.0 Ubuntu 5.04, 5.10, 6.04, 6.10, 7.04, 7.10, 8.04, 8.10, 9.04, 9.10 Mandriva 2005LE, 2006, 2007, 2007.1, 2008, 2008.1, 2009, 2009.1
		Mac OS 10.3 ~ 10.6	Mac OS 10.3 ~ 10.6
		Citrix Presentation Server Windows Terminal Services	Citrix Presentation Server Windows Terminal Services
	WHQL	Windows 2000/XP(32/64bits)/ Vista(32/64bits)/2003 Server(32/64bits)/2008 Server(32/64bits)/ 7(32/64bit)/2008 Server R2(64bits)	Windows 2000/XP(32/64bits)/ Vista(32/64bits)/2003 Server(32/64bits)/2008 Server(32/64bits)/ 7(32/64bit)/2008 Server R2(64bits)
	Compatibility	SPL: Win 2000/XP(32/64bits)/2003 Server(32/64bits)/Vista(32/64bits)/2008 S erver(32/64bits)/7(32/64bits)/2008 Server R2	SPL & PCL6: Win 2000/ XP(32/64bits)/2003 Server(32/64bits)/ Vista(32/64bits)/2008 Server(32/64bits)/7(32/64bits) PS3: Win 2000/XP(32/64bits)/ Vista(32/64bits)/2003 server(32/64bits)/2008 Server(32/64bits)/7 (32/64bits) PPD, Mac PPD, Linux PPD
Wired Network	Protocol	- 331xD : N/A - 331xND : TCP/IP, Ethertalk, SNMP, HTTP 1.1	- 371xD : N/A - 371xND/ 371xDW : TCP/IP, Ethertalk, SNMP, HTTP 1.1
	Supporting OS	- 331xD : N/A - 331xND : Windows 2000/XP(32/64bits)/2003 Server(32/64bits)/Vista(32/64bits)/2008 Server(32/64bits) Mac OS 8.6~9.2, 10.1~10.5 Various Linux OS including Red Hat 8~9, Fedora Core 1~4, Mandrake 9.2~10.1, and SuSE 8.2~9.2 NetWare 5.x, 6.x (TCP/IP Only) Unix HP-UX	- 371xD : N/A - 371xND / 371xDW : Windows 2000/XP(32/64bits)/2003 Server(32/64bits)/Vista(32/64bits)/2008 Server(32/64bits) Mac OS 8.6~9.2, 10.1~10.5 Various Linux OS including Red Hat 8~9, Fedora Core 1~4, Mandrake 9.2~10.1, and SuSE 8.2~9.2 NetWare 5.x, 6.x (TCP/IP Only) Unix HP-UX
Wireless Network	Protocol	N/A	- 371xD / 371xND : N/A - 371xDW : 802.11n

## 2. Product specifications and descriptions

Item		ML-331x series	ML-371x series
Application	Smart Panel	SmartPanel for Windows/ Macintosh/ LINUX	SmartPanel for Windows/ Macintosh/ LINUX
	Printer Setting	PSU for Windows/ Macintosh/LINUX	PSU for Windows/ Macintosh/LINUX
	Network Management	- 331xD : N/A - 331xND : SyncThru Web Admin Service 5.0	- 371xD : N/A - 371xND/ 371xDW : SyncThru Web Admin Service 5.0
	IP Setting	- 331xD : N/A - 331xND : SetIP	- 371xD : N/A - 371xND/ 371xDW : SetIP
<b>Interface</b>			
IEEE 1284 Parallel		Optional	Optional
USB		Hi-Speed USB 2.0	Hi-Speed USB 2.0
Wired Network		- 331xD : N/A - 331xND : Ethernet 10/100 Base TX (Internal)	- 371xD : N/A - 371xND / 371xDW : Ethernet 10/100/1000 Base TX (Internal)
Wireless Network		N/A	371xDW only
<b>User Interface</b>			
LCD		- 331xD : N/A - 331xND : 2-Line	2-Line
LED		4EA: ECO(1), Power(1), Status(2)	- 371xD / 371xND : 4EA( ECO(1), Power(1), Status(2)) - 3710xW : 5EA (ECO(1), Power(1), Status(2), WPS(1))
Key		- 331xD : 3EA (ECO, Power, Cancel) - 331xND : 8EA (5 Navigation keys, ECO, Power, Cancel)	- 371xD / 371xND : 8EA (5 Navigation keys, ECO, Power, Cancel) - 371xDW : 9EA (5 Navigation keys, ECO, WPS, Power, Cancel)

## 2. Product specifications and descriptions

## 2.1.3.3 Paper Handling

Item		ML-331x series	ML-371x series
Standard Capacity		250-sheet Cassette Tray, 1-sheet (331xD)/ 50-sheet (331xND) Multi Purpose Tray @80g/m <sup>2</sup>	250-sheet Cassette Tray, 50-sheet Multi Purpose Tray @80g/m <sup>2</sup>
Max. Capacity		- 331xD : 251 sheets @ 80g/m <sup>2</sup> - 331xND : 820 sheets @ 80g/m <sup>2</sup>	820 sheets @ 80g/m <sup>2</sup>
Printing	Max. Size	216 x 356 mm (8.5" x 14")	216 x 356 mm (8.5" x 14")
	Min. Size	76 x 127 mm (3.0" x 5.0")	76 x 127 mm (3.0" x 5.0")
<b>Multi-purpose tray</b>			
Capacity	Plain Paper	- 331xD : 1 sheet @ 80g/m <sup>2</sup> - 331xND : 50 sheets @ 80g/m <sup>2</sup>	50 sheets @ 80g/m <sup>2</sup>
	Envelop	- 331xD : 1 sheet - 331xND : 5 sheets	5 sheets
Media sizes		A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5, 3"x5", Envelope(Monarch, No.10, DL, C5, C6), Custom	A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5, 3"x5", Envelope(Monarch, No.10, DL, C5, C6), Custom
Media type		Plain, Thin, Thick, Thicker, Cotton, Colored, Envelope, Transparency, Pre-Printed, Recycled, Labels, Bond, Card stock, Archive	Plain, Thin, Thick, Thicker, Cotton, Colored, Envelope, Transparency, Pre-Printed, Recycled, Labels, Bond, Card stock, Archive
Media weight		16~58lb (60 to 220g/m <sup>2</sup> )	16~58lb (60 to 220g/m <sup>2</sup> )
Sensing		- 331xD : N/A - 331xND : Paper Empty	Paper Empty
<b>Standard Cassette Tray</b>			
Capacity		250 sheets @ 80g/m <sup>2</sup>	250 sheets @ 80g/m <sup>2</sup>
Media sizes		A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5, Custom	A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5, Custom
Media types		Plain Paper, Thin, Thick, Recycled, Bond, Cardstock, Archive	Plain Paper, Thin, Thick, Recycled, Bond, Cardstock, Archive
Media weight		16~43lb (60 to 163g/m <sup>2</sup> )	16~43lb (60 to 163g/m <sup>2</sup> )
Sensing		Paper Empty	Paper Empty
<b>Optional Cassette Tray</b>			
Capacity		- 331xD : N/A - 331xND : 520 sheets @ 80g/m <sup>2</sup>	520 sheets @ 80g/m <sup>2</sup>
Media sizes		- 331xD : N/A - 331xND : A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5	A4, A5, A6, Letter, Legal, Folio, Oficio, Executive, ISO B5, JIS B5
Media types		- 331xD : N/A - 331xND : Plain Paper, Thin, Thick, Recycled, Bond, Cardstock, Archive	Plain Paper, Thin, Thick, Recycled, Bond, Cardstock, Archive

## 2. Product specifications and descriptions

Item		ML-331x series	ML-371x series
Media weight		- 331xD : N/A - 331xND : 16~43lb (60 to 163g/m <sup>2</sup> )	16~43lb (60 to 163g/m <sup>2</sup> )
Sensing		- 331xD : N/A - 331xND : Paper Empty	Paper Empty
<b>Output Stacking</b>			
Capacity	Face-Down	150 sheets @ 80g/m <sup>2</sup>	150 sheets @ 80g/m <sup>2</sup>
	Face-Up	1 sheet	1 sheet
Output Full sensing		Yes	Yes
<b>Duplex</b>			
Supporting		Built-in	Built-in
Media sizes		A4, Letter, Oficio, Folio, Legal	A4, Letter, Oficio, Folio, Legal
Media types		Plain Paper, Thin, Thick, Recycled, Bond	Plain Paper, Thin, Thick, Recycled, Bond
Media weight		16~32lb (60 to 120g/m <sup>2</sup> )	16~32lb (60 to 120g/m <sup>2</sup> )
<b>Printable Area</b>			
Non-Printable Area	Envelop	10mm(0.4") from edge(Top, Bottom, Left, Right)	10mm(0.4") from edge(Top, Bottom, Left, Right)
	Other Media	4mm(0.16") from edge(Top, Bottom, Left, Right)	4mm(0.16") from edge(Top, Bottom, Left, Right)

## 2.1.3.4 Consumables

Item		ML-331x series	ML-371x series
Toner	Black	- Standard: Average Cartridge Yield 2K standard pages. - High Yield: Average cartridge Yield 5K standard pages. Declared cartridge yield in accordance with ISO/IEC 19752.	- Standard: Average Cartridge Yield 2K standard pages. - High Yield: Average cartridge Yield 5K standard pages. - Extra High Yield: Average cartridge Yield 10K standard pages. Declared cartridge yield in accordance with ISO/IEC 19752.
	Key	Electronic key(CRUM) Only	Electronic key(CRUM) Only
	Life detect	Toner gauge sensor by dot count	Toner gauge sensor by dot count
Drum	Yield	N/A	N/A

## 2. Product specifications and descriptions

**2.1.3.5 Reliability & Service**

Item	ML-331x series	ML-371x series
Recommended AMPV	1000 sheets/month	1500 sheets/month
Max AMPV	2500 sheets/month	3500 sheets/month
Max. Monthly Duty	50,000 sheets/month	80,000 sheets/month
MPBF	35,000 sheets	45,000 sheets
MTBF	35 months	35 months
MTTR	30 min.	30 min.
SET Life Cycle	170,000 sheets or 5 years (whichever comes first)	220,000 sheets or 5 years (whichever comes first)

**2.1.3.6 Maintenance part**

Item	Part Code	Life
Transfer roller	JC66-02842A	Approx. 100,000 Pages
Fuser Unit	JC91-01023A (110V) JC91-01024A (220V)	Approx. 90,000 Pages
Pick-up Roller	JC73-00340A	Approx. 90,000 Pages
Retard Roller	JC90-01032A	Approx. 60,000 Pages

## 2. Product specifications and descriptions

## 2.1.3.7 Environment

Item		ML-331x series	ML-371x series
Operating Environment	Temperature	10C to 32C	10C to 32C
	Humidity	20% to 80%	20% to 80%
Acoustic Noise Level(Sound Power/ Pressure)	Printing	51dBA	52dBA
	Standby	26 dBA	26 dBA
	Sleep	Back Ground Level	Back Ground Level
Power Consumption	Ready	Less than 55W	Less than 55W
	AVG.	Less than 550W	Less than 600W
	Max/Peak	Less than 600W	Less than 650W
	Sleep / Power Off	Less than 8W / Less than 0.4W (Conformity to EPA)	Less than 8W / Less than 0.4W (Conformity to EPA)
Dimension (W x D x H) (W x D x H)	SET	366 x 368 x 240.6	366 x 368 x 240.6
Weight	SET	9.0Kg	9.0Kg

## 2.1.3.6 Options





Item	ML-331x series	ML-371x series
Memory	N/A	256MB
Second Cassette	- 331xD : N/A - 331xND : 520-sheet Cassette Tray	520-sheet Cassette Tray
Wireless Network	N/A	N/A
Hard Disk	N/A	N/A

## 2.1.3.8 Others

Item		ML-331x series	ML-371x series
Memory	Upgradable Mem. Slot	N/A	YES
	Upgradable Mem. Type	N/A	SODIMM
	Upgradable Mem. Unit	N/A	256MB
Sensor	Paper Empty	YES	YES
	Paper Size	NO	NO
	Media Type	NO	NO
	Paper Full	YES	YES

## 2. Product specifications and descriptions

## 2.1.4 Model Comparison Table


	Samsung ML-3710 series	Samsung ML-3310 series	HP P2050 series	Lexmark E360dn
Image				
Speed	35 ppm (A4) 37 ppm (Letter)	31 ppm (A4) 33 ppm (Letter)	33 ppm (A4)	38 ppm (A4)
Processor	600 MHz	375 MHz	600 MHz	400 MHz
Memory (Std/Max)	371xD (64/320 MB) 371xND/DW (128/384MB)	64 / 64 MB	P2055dn (128/384 MB) P2055d (64/320MB)	32 / 288 MB
Emulation	PCL6/5e, PS3	SPL, PCL5e	PCL6	PCL6/PS3
MP/Cassette	50 / 250	1 / 250 (331xD) 50 / 250 (331xND)	50 / 250	50 / 250
SCF	520 sheets	N/A (331xD) / 520 sheets (331xND)	500 sheets	550 sheets
Duplex	Std.	Std.	Std.	Std.
Toner Yield	2K/ 5K / 10K	2K / 5K	2.3K/ 6.5K	3.5K / 9K
Interface	- High speed USB 2.0 - Ethernet 10/100/1000 Base TX (371xND/DW) - Wireless LAN (371xDW)	- High speed USB 2.0 - Ethernet 10/100 Base TX (331xND)	- High speed USB 2.0 - Ethernet 10/100/1000 Base TX (P2055dn)	- High speed USB 2.0 - Ethernet 10/100 Base TX
Noise	52dB	51dB	55dB	53dB



## 2.2 Product Description

This chapter describes the functions and operating principal of the main component.


### 2.2.1 Front View



<b>1</b>	Output tray	<b>7</b>	Tray 1
<b>2</b>	Control panel	<b>8</b>	Multi-purpose tray
<b>3</b>	Control board cover	<b>9</b>	Multi-purpose tray paper extension
<b>4</b>	Front cover	<b>10</b>	Paper width guides on a multi-purpose tray
<b>5</b>	Paper level indicator	<b>11</b>	Output support
<b>6</b>	Optional tray 2 <sup>a</sup>		

a. Optional device.


2.2.2 Rear View



1	Network Port <sup>a</sup>	5	Power receptacle
2	USB port	6	Duplex unit
3	Output 5V	7	Rear cover
4	Power Switch (Only Korea)		

a. Available only with models that support network connection.


### 2.2.3 Paper Path



## 2. Product specifications and descriptions

## 2.2.4 System layout

This model is consisted of the Engine parts and F/W. The engine parts is consisted of the mechanical parts comprising Frame, Feeding, Developing, Driving, Transferring, Fusing, Cassette and H/W comprising the main control board, power board, operation panel, PC Interface.




1	LSU	7	Cassette
2	Cartridge	8	Duplex
3	Regi roller	9	Fuser
4	MP	10	Exit roller1
5	Feed roller	11	Exit roller2
6	Pick up roller		

### 2.2.4.1 Feeding Part

It consists of a basic cassette, an MP tray for supplying different types of media (envelope, label, special paper) and parts related to paper transferring.


#### 1) Basic cassette

The paper trays consist of the Main trays, Optional trays (SCF), and one Multi-Purpose (MP) tray. The basic cassette is located on front side of the machine and allows feeding of common paper. Paper size is set using the Size Guides in each tray. Adjust the Paper length/width guides to match the paper size.



#### 2) Pick up / Retard Roller

When pickup takes place, the pickup roller rotates to separate and transport the paper. The pickup roller rotates when the pickup clutch is activated. The retard roller serve to make sure that a single sheet of paper is moved to the paper path, and the paper is moved as far as the registration roller by the work of the feed roller. The following is a diagram of the pickup section:




## 2. Product specifications and descriptions

### 3) Registration roller

It has a paper arranging function, paper transferring function, paper detecting function, jam removing function, and so on.

### 4) MP tray

The multi-purpose tray can hold special sizes and types of print material, such as postcards, note cards, and envelopes. It is useful for single page printing on letterhead or colored paper. It uses 3 rollers feeding method to feed 50 sheets (371x series / 331xND) or 1 sheet (331xD) of general papers.



### 5) Duplex unit

It has paper transferring function, paper guide function, jam removing function.

It is designed for basic attachment, and the duplex feeding takes a side feeding method. Usable papers are A4, letter, and legal size paper. For removing a jam occurred in a front part, it is designed to open a cassette and a guide. It is designed to open a rear cover to remove a jam in a rear part. If a face up tray is open, the duplex option cannot be used.


### 6) SCF (Second Cassette Feeder)

It is the same method with the main cassette, and the capacity is 520 sheets.

It has a separate driving mechanism. It is designed for a common use with a main cassette.

### 2.2.4.2 Imaging unit

#### 1) Printing process overview



This mono printing system includes the LSU with a laser beams, a toner cartridge and transfer roller.

This machine uses single toner cartridge and dual laser beams for mono printing. The toner cartridge consists of Drum unit and Development unit. The Drum unit has an OPC drum, cleaning blade.


The OPC drum is charged with a negative voltage by the scorotron and is exposed by the light from the LSU (Laser Scanning unit). The light produced by a laser creates a latent image by discharging on the surface of the OPC drum. The negatively charged toners are attracted to the latent image due to an electric field. The toners (real image) on the OPC drum are moved to the transfer media by the positive bias applied to the transfer roller.

- 1. Charging the OPC drum:** The scorotron gives the drum negative charges.
- 2. Laser exposure:** Light produced by a laser diode irradiates the charged OPC through the lens and mirrors.
- 3. Development:** This machine uses a dual-component development system. The magnetic roller carries negatively charged toner to the latent image on the drum surface.
- 4. Transfer:** The transfer rollers opposite the OPC drums transfer toner from the drums to the transfer media (e.g. paper, OHP film, etc).
- 5. Cleaning for OPC drum:** The cleaning blade removes remaining toners on the drum surface after image transfer to the paper.

## 2) Toner cartridge

By using the electronic photo process, it creates a visual image. In the toner cartridge, the OPC unit and the developing unit are in a body. The OPC unit has OPC drum and charging roller, and the toner cartridge unit has toner, supply roller, developing roller, and blade (Doctor blade)

- Operation condition : Temp 10~30℃, Humidity 20~85% RH
- Developing Method : Non magnetic 1 element contacting method
- Toner : Non magnetic 1 element shatter type toner
- The life span of toner (ISO 19752 pattern / A4 standard)
  - Initial toner : 2K (331x series) / 5K (337x series)
  - Sales toner : 2K / 5K / 10K(only 337x series)
- Toner Residual Sensor : Dot count with CRUM(CRU Monitor)
- OPC Cleaning : Collect the toner by using cleaning blade
- Handling of wasted toner : Collect the wasted toner in the cleaning frame by using cleaning blade
- OPC Drum Protecting Shutter : None
- Classifying device for toner cartridge: ID is classified by CRUM.




(a)	Charge Roller	(f)	Supply Roller
(b)	Drum OPC	(g)	Charge Cleaning Roller
(c)	Cleaning Blade	(h)	Agitator 1
(d)	Doctor Blade	(i)	Agitator 2
(e)	Developer Roller		



### 2.2.4.3 Fuser unit

It is consisted of a halogen lamp, heat roller, pressure roller, thermistor and thermostat. It sticks the toner on a paper by heat and pressure to complete the printing job.



#### 1) Thermostat

When a heat lamp is overheated, a Thermostat cuts off the main power to prevent over- heating.

- Thermostat Type : Non- Contact type THERMOSTAT
- Control Temperature :  $170^{\circ}\text{C} \pm 5^{\circ}\text{C}$

#### 2) Thermistor

It is a temperature detecting sensor.

- Temperature Resistance :  $7\text{k}\Omega$  ( $180^{\circ}\text{C}$ )

#### 3) Heat roller

The heat roller transfers the heat from the lamp to apply a heat on the paper.

The surface of a heat roller is coated with Teflon, so toner does not stick to the surface.


#### 4) Pressure roller

A pressure roller mounted under a heat roller is made of a silicon resin, and the surface also is coated with Teflon. When a paper passes between a heat roller and a pressure roller, toner adheres to the surface of a paper permanently.

#### 5) Halogen Lamp


- Voltage 120 V :  $115 \pm 5 \%$   
220 V :  $230 \pm 5 \%$
- Capacity :  $850 \text{ Watt} \pm 25 \text{ W}$

It is the core part of the LBP which switches from the video data received to the controller to the electrostatic latent image on the OPC drum by controlling laser beam, exposing OPC drum, and turning principle of polygon mirror. The OPC drum is turned with the paper feeding speed. The /HSYNC signal is created when the laser beam from LSU reaches the end of the polygon mirror, and the signal is sent to the controller. The controller detects the /HSYNC signal to adjust the vertical line of the image on paper. In other words, after the /HSYNC signal is detected, the image data is sent to the LSU to adjust the left margin on paper. The one side of the polygon mirror is one line for scanning.



The ML-331x series Electrical Circuit System consists of the following:

- ### Diagram of the ML-331x Series Electrical Circuit



---

## 2. Product specifications and descriptions

---

The Main Controller adopts the Jupiter5(375MHz) CPU, on board DDR2 memory to perform printing jobs successfully.

The OPE Controller displays the status of the system using 16 x 2line LCD in response to user actions or the Main controller.

ML-331xD model only supports LED OPE without LCD module.

The HVPS supplies high voltage for developing Process. High Voltage controlled by PWM signal from CPU.

SMPS makes +5V and +24V DC from 220V or 110 AC.

- Main Controller
- OPE Controller
- DDR2 SODIMM(Optional)
- WLAN Module(371xDW only)
- SCF(Optional)
- SMPS
- HVPS

[illegible]Service Manual  
ML-331x/371x series

---

## 2. Product specifications and descriptions

---

The Main Controller adopts the CHORUS4(600MHz) CPU, on board DDR2 memory and external memory to perform printing jobs successfully.

The OPE Controller displays the status of the system using 16 x 2line LCD in response to user actions or the Main controller.


The HVPS supplies high voltage for developing Process. High Voltage controlled by PWM signal from CPU.

SMPS makes +5V and +24V DC from 220V or 110 AC.

WLAN module is used for wireless communication.

## Circuit Board Locations

The following diagrams show the locations of the printer circuit boards:





## 2. Product specifications and descriptions


## 2.2.5.1 Main controller

ML-331x series Main Controller is composed with below components

- JUPITER5 : To generate the printable video data and control engine  
Embedded USB2.0 device
- On board DDR2 SDRAM : system memory(64MB)
- Ethernet PHY : Network printing
- Serial Flash : Program memory  
ML-331xD : 8MB, ML-331xND : 16MB

The Main Controller manages an Electro-photography system, controls the Video Data of printing images from Main Board to LSU, provides high-voltages and PWMs, adjusts temperature in the fusing system, reads sensor signals and controls SCF option.

The Main controller also controls OPE and N/W PHY, USB Device.




[ Main Controller Diagram ]



## 2. Product specifications and descriptions

## ML-331x series Main Controller Printed Circuit Board Assembly



## • Connection

1	HVPS	12	Air temperature
2	Paper Empty, Regi, Feed sensor	13	FAN SMPS
3	OPE	14	Main Motor & Clutch
4	CRUM	15	SCF
5	THERMISTOR	16	SMPS Signal
6	Outbin Full Sensor & Rear Cover	17	SMPS Power
7	ERASER	18	MP
8	N/W	19	DEBUG
9	USB Device	20	LSU
10	Parallel Option DC supply jack	21	FAN MAIN
11	Exit Sensor		

## • Information

- SEC-CODE : JC92-02329A
- PBA Name : PBA-MAIN


## 2. Product specifications and descriptions

ML-371x series Main Controller is composed with below components

- CHORUS4 : To generate the printable video data and control engine  
Embedded USB2.0 device, Host channel
- On board DDR2 SDRAM and external DDR2 SO-DIMM : system memory  
On board DDR2 - 371xD : 64MB, 371xND/DW :128MB  
External DRR2 SO-DIMM : 128MB, 256MB
- Giga Ethernet PHY : Network printing
- Serial Flash(16MB) : Program memory
- Engine Controller(LEPC1) : ADC, DAC, Clutch, Fuser control

The Main Controller manages an Electro-photography system, controls the Video Data of printing images from Main Board to LSU, provides high-voltages and PWMs, adjusts temperature in the fusing system, reads sensor signals and controls SCF option.


The Main controller also controls OPE and Giga N/W PHY, USB Device, Wireless Module.



[ Main Controller Diagram ]

## 2. Product specifications and descriptions

## ML-371x series Main Controller Printed Circuit Board Assembly



## • Connection

1	HVPS
2	Paper Empty, Regi, Feed sensor
3	WLAN
4	OPE
5	CRUM
6	THERMISTOR
7	Outbin Full Sensor & Rear Cover
8	ERASER
9	N/W
10	USB Device
11	Parallel Option DC supply jack
12	Debug
13	Exit Sensor
14	Air temperature
15	FAN SMPS
16	Main Motor & Clutch
17	SCF
18	JTAG
19	SMPS Signal
20	SMPS Power
21	MP
22	LSU
23	FAN MAIN
24	DDR2 SODIMM

## • Information

- SEC-CODE : JC92-02343A
- PBA Name : PBA-MAIN

## 2. Product specifications and descriptions

## 2.2.5.2 OPE Controller

The OPE Controller is composed of an OPE MICOM(STM8SP103K3MAFTR), two status LED, ECO LED, power LED, WPS LED(ML-371xDW model only), 16x2 line LCD and some keys. OPE communicates with main controller via UART.

ML-3710D model OPE is composed of LEDs and KEYS without LCD.

## Diagram of OPE Controller




## OPE Controller PBA



## • Information

- SEC-CODE : JC92-02341A
- PBA Name : OPE-LCD



## • Information

- SEC-CODE : JC92-02342A
- PBA Name : OPE-LED



## 2. Product specifications and descriptions

### 2.2.5.3 SO-DIMM PBA(ML-371x series) - Optional

The SO-DIMM PBA is the system Memory module of the Main Controller. It is used for the operating system, some system application programs, and it stores some print data from the USB and Network port. There are two kinds of SO-DIMM PBA:

- 128MB & 256MB capacity



#### • Information

- SEC-CODE : JC92-01923A 128MB  
JC92-01975A 256MB
- PBA Name : PBA RAM DIMM

### 2.2.5.4 WLAN(ML-371xDW model only)

The Wireless LAN Module supports 802.11b/g/n at only 371xDW model via USB 2.0 high speed. The Module is installed at the USB Host Channel of Main Controller PBA.



#### • Information

- SEC-CODE : JC92-02364A
- PBA Name : PBA-WNPC

## 2. Product specifications and descriptions

## 2.2.5.5 SCF PBA - Optional

The SCF PBA is the SCF control board. It use UART communication with main controller.  
S3F443FX is used as a microcontroller.  
ML-3310D model doesn't support SCF.



## • Information

PBA Name : PBA-SCF

## 2.2.5.6 CRUM PBA

ML-3X10 series use same CRUM PBA as ML-1660.  
CRUM PBA use I2C communication with main Controller.



## • Information

- SEC-CODE : JC92-02055B
- PBA Name : PBA-CRUM




### 2.2.5.7 Connection Part

Controller require connections to all of the system units such as the BLDC motor, Clutch, Sensor, and other PBAs(OPE, HVPS, SMPS). The Main Controller contains various types of connectors, to deliver electronic signals through signal wires. The signal wires provide electronic control signals that are used for starting and stopping the motors, operating clutches, sensing the unit state, etc.

## 2. Product specifications and descriptions

## 2.2.5.8 SMPS Board

The SMPS (Switching Mode Power Supply) Board supplies electric power to the Main Board and other boards through a Main Controller. The voltage provided includes +5V, and +24V from a 110V/220V power input.



## • Specification

General Input/Output Voltage

1) AC 110V (90V ~ 135V)

2) AC 220V (180V ~ 270V)

3) Output Current:

-.+5V : 1.6A

-.+24V : 1.8A

3) Output Power:

-.+5V : 8.16W

-.+24V : 43.2W

5) Heat Lamp Capacity : 850W

## • Information

	110V	220V
SEC CODE	JC44-00095D	JC44-00096D
PBA NAME	SMPS V1	SMPS V2


## • Connection

1	INPUT_AC
2	Fuser_AC Output
3	SMPS Control Signal (from Engine PBA)
4	OUTPUT_5V&24V (to DC POWER PBA)



### 2.2.5.9 HVPS Board

The ML-331x /371x series contains a High Voltage Power Supply(HVPS) board. This board generates high-voltage channels which includes MHV, DEV, BLADE, SUPPLY, OPC, THV and FUSER BIAS.



#### • Connection


1	Main Interface	5	SUPPLY(-489V)
2	MHV(-1240V)	6	OPC(-51V)
3	DEV(-338V)	7	THV(+1315V, -1000V)
4	BLADE(-389V)	8	FUSER BIAS(240V)

#### • Information

- SEC-CODE : JC44-00197A
- PBA Name : HVPS


## 2.2.5.10 Electrical Parts Location

## 1) Sensors




1	Cassette paper empty sensor	4	Feed sensor
2	MP paper empty sensor	5	Exit sensor
3	Regi sensor	6	Outbin full sensor

## 2) Motor and clutch



1	Main motor	3	Cassette Pick up clutch
2	Regi clutch	4	MP Pick up clutch

## 3) Fan



1	Main fan	2	SMPS fan
---	----------	---	----------

## 2.2.6 Engine F/W Control Algorithm

### 2.2.6.1 Feeding

If feeding from a cassette, the drive of the pickup roller is controlled by controlling the solenoid. The on/off of the solenoid is controlled by controlling the general output port or the external output port. While paper moves, occurrence of Jam is judged as below.

ITEM	Description
JAM 0	<ul style="list-style-type: none"> <li>- After picking up, paper cannot be entered because paper is not fed.</li> <li>- After picking up, paper entered but it cannot reach to the feed sensor in certain time due to slip, etc.</li> <li>- After picking up, if the feed sensor is not on, re-pick up. After re-picking up, if the feed sensor is not on after certain time, it is JAM 0.</li> </ul>
JAM 1	<ul style="list-style-type: none"> <li>- After the leading edge of the paper passes the feed sensor, the trailing edge of the paper cannot pass the feed sensor after a certain time.</li> <li>- After the leading edge of the paper passes the feed sensor, the paper cannot reach the exit sensor after certain time.</li> </ul> <p><i>*The paper exists between the feed sensor and the exit sensor.</i></p>
JAM 2	<ul style="list-style-type: none"> <li>- After the trailing edge of the paper passes the feed sensor, the paper cannot pass the exit sensor after certain time.</li> </ul>

### 2.2.6.2 Transfer

The charging voltage, developing voltage and the transfer voltage are controlled by PWM (Pulse Width Modulation). The each output voltage is changeable due to the PWM duty. The transfer voltage admitted when the paper passes the transfer roller is decided by environment recognition. The resistance value of the transfer roller is changed due to the surrounding environment or the environment of the set, and the voltage value, which changes due to the environments, is changed through AD converter. The voltage value for impressing to the transfer roller is decided by the changed value.



### 2.2.6.3 Fusing

The temperature change of the heat roller's surface is changed to the resistance value through the thermistor.

By converting the voltage value, which impressed to the resistance, to the digital value through the AD converter, the temperature is decided. The AC power is controlled by comparing the target temperature to the value from the thermistor. If the value from the thermistor is out of controlling range while controlling the fusing, the error stated in the below table occurs.

- **Open Heat Error**

When the engine operates the warm-up process, if the temperature of the fixing unit is not higher than a specified temperature, the engine defines Open Heat Error. When this error is broken out, the engine stops all functions and keeps the error state. Also, the engine informs the error status of the main system. And then the error message is displayed at LCD window or LED informing the error status of the user.

- **Low Heat Error**

When the engine is at stand-by, printing or warm-up mode, if the temperature of the fixing unit is lower than the specified temperature at each state and the lower temperature state is maintained during the specified time, the engine defines Low Heat Error. When this error is broken out, the engine stops all functions and keeps it at the error state. Also the engine informs the error status of the main system. And then the error message is displayed at LCD window or LED informing the error status of the user.

- **Over Heat Error**

For overall engine state, if the temperature of the fixing unit is higher than the specified temperature and the temperature state is kept during the specified time, the engine defines Over Heat Error. When this error is broken out, the engine stops all functions and keeps it at the error state. Also, the engine informs the error status of the main system. And then the error message is displayed at LCD window or LED to inform the error status of the user.

#### 2.2.6.4 LSU

LSU receives the image data from PVC or HPVC and make the latent image on OPC surface. It uses the single beam, LD. The errors related to LSU are as follows:

- **By Lready**

When the printing is started, the engine drives the polygon motor of LSU. After the specified time is elapsed, if the motor is not in a ready status, the engine detects the error that the polygon motor is not in a ready status. If this error happens, the engine stops all functions and keeps it at the error state. Also, the engine informs the error status of the main system and the error message is displayed at LCD window to inform the error status of the user.

- **By Hsync**

When the polygon motor is ready, the LSU sends out the signal called Hsync and used to synchronize with each image line. So, if the engine does not detect consecutively the signal for a fixed time, it defines the Hsync Error. If this error happens, the engine stops all functions and keeps it at the error state. Also, the engine informs the error status of the main system and then the error message is displayed at LCD window to inform the error status of the user. LSU Error Recovery: If the LReady or Hsync error happens, the paper exits out beforehand. The engine mode is changed to recovery mode and the engine informs the main system of the engine mode. And the engine checks the LSU error. If the error doesn't happen, the printing job.


## 2.2.7 S/W Descriptions

### 2.2.7.1 Overview

The software of ML-331x /337x series system is constructed with

- 1) Host Software part that the application software operated in Window and Web Environment, and
- 2) Firmware parts that is a Embedded software controls printing job.

### 2.2.7.2 Architecture



#### Host Software is made up of


1. Graphic User Interface that offers the various editing functions to user in Host,
2. Driver that translates the received document to a Printing Command language which printer can understand and transfers data to spooler,
3. Stand-alone Application that offers the various printing application, PSU(Printer Settings Utility), Printer Status Monitor, Network Management in Window system,
4. Web-based-Application that offers the same functions as Stand-alone Application and RDC(Remote Diagnosis Control) in Web environment.

#### Firmware is made up of

1. Application (Emulation) that is a interpreter translate data received from Host to a printing language (PCL, PS, GDI, etc.) to be able to make the user to take same output as originally one what composed in Host.
2. Kernel that control and management the whole procedure include of Control flow and Printing Job before transfer to Engine system.



## 2.2.7.3 Data and Control Flow



Note: (\*) is role of N/W I/F

The above Block Diagram is explained that:

Host Side is made up of

1. Driver that is Windows application software translate printed data to one of printer language and create spooler file.
2. Web-based Application that offer a various printer additional functions, management of printing job, printer administration, Status monitor to monitoring the printer status by real time in Web, independent environment on OS.
3. Stand-alone Application that is a similar Window software as same as above 2,
4. Port Monitor that manages the network communication between spooler and Network Interface Card, or various additional application and Network Interface Card,(this is, at first, make communication logical port, manage the data, transfer them from spooler to network port, and offer the result of printing).

**Firmware Side is made up of**

1. Network Interface Card is that relay the communication between Host and kernel using various network protocol.
2. Kernel is that manages the flow control of emulation procedure, receiving data from Host or Network card and printing with engine & rendering job,
3. Emulation is that interprets the various output data from selected emulation,
4. Engine is that prints rendered bit-map data to paper with required size and type by Kernel.

And then, for Job Spooling function for Multi-User, Multi-Printing that is occurred in Network printing and various additional printing functions, this Kernel use max. 10 Queuing systems in a memory.

**In Printing, the two procedures are****(1) Case of using USB Port**

- After user start to print the wanted document to PCL string or compressed GDI bit-map data, Driver translate the all graphic data of it and send data to host spooler. And then the spooler sends the data stream to the printer via USB port.
- Kernel receives this data from Host, and then select emulation fit to data and start selected one. After emulation job end, Kernel sends the output bit-map data to Engine using Printer Video Controller (by clock type for LSU).
- Engine print the received data to required paper with the sequential developing process.

**(2) Case of using Network Interface Card**

- After user start to print the wanted document to PCL string or compressed GDI bit-map data, Driver translate the all graphic data of it and send data to host spooler.
- If so, Port monitor managing network port receives data from spooler and sends a data stream to the Network Interface Card.
- Network interface card receives it and send to Kernel part.
- Kernel receives this data from Host, and then select emulation fit to data and start selected one. After emulation job end, Kernel sends the output bit-map data to Engine using Printer Video Controller (by clock type for LSU).
- Engine print the received data to required paper with the sequential developing process.

## 3. Disassembly and Reassembly

### 3.1 General Precautions on Disassembly

When you disassemble and reassemble components, you must use extreme caution. The close proximity of cables to moving parts makes proper routing a must.

If components are removed, any cables disturbed by the procedure must be restored as close as possible to their original positions. Before removing any component from the machine, note the cable routing that will be affected.


**Whenever servicing the machine, you must perform as follows:**

1. Check to verify that documents are not stored in memory.
2. Be sure to remove the toner cartridge before you disassemble parts.
3. Unplug the power cord.
4. Use a flat and clean surface.
5. Replace only with authorized components.
6. Do not force plastic-material components.
7. Make sure all components are in their proper position.

#### Releasing Plastic Latches

Many of the parts are held in place with plastic latches. The latches break easily; release them carefully.

To remove such parts, press the hook end of the latch away from the part to which it is latched.



### 3.2 Screws used in the printer


The screws listed in the table below are used in this printer. Please ensure that, when you disassemble the printer, you keep a note of which screw is used for which part and that, when reassembling the printer, the correct screws are used in the appropriate places.

Part Code	Location	Description	Qty
6002-000440	DUPLEX	SCREW-TAPPING;PWH,+,2,M3,L8,ZPC(BLK),SWRCH18A	5
6003-000196	FRAME MAIN	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	20
6003-000261		SCREW-TAPTYPE;BH,+,-,B,M3,L6,ZPC(WHT),SWRCH18A,-	2
6003-000269		SCREW-TAPTYPE;BH,+,-,S,M3,L6,ZPC(WHT),SWRCH18A,-	3
6003-000196	MP	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	2
6003-000196	FUSER	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	5
6003-000269		SCREW-TAPTYPE;BH,+,-,S,M3,L6,ZPC(WHT),SWRCH18A,-	3
6003-000282		SCREW-TAPTYPE;BH,+,-,B,M3,L8,ZPC(BLK),SWRCH18A,-	4
6003-000269	DRIVE	SCREW-TAPTYPE;BH,+,-,S,M3,L6,ZPC(WHT),SWRCH18A,-	6
6003-000196	FRAME-ETC	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	38
6003-000261		SCREW-TAPTYPE;BH,+,-,B,M3,L6,ZPC(WHT),SWRCH18A,-	3
6003-000301		SCREW-TAPTYPE;BH,+,S,M4,L6,ZPC(WHT),SWRCH18A	1
6006-001078	FRAME-ETC	SCREW-TAPTYPE;PH,+,WSP,B,M3,L10,ZPC(WHT),SWRCH18A	1
6003-000282	LSU	SCREW-TAPTYPE;BH,+,-,B,M3,L8,ZPC(BLK),SWRCH18A,-	5
6003-000196	COVER-TOP	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	3
6003-000196	COVER-FRONT	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	2
6003-000264	MP GUIDE-TRAY	SCREW-TAPTYPE;PWH,+,B,M3,L6,ZPC(WHT),SWRCH18A,-	1
6003-000282	CARTRIDGE-TONER	SCREW-TAPTYPE;BH,+,-,B,M3,L8,ZPC(BLK),SWRCH18A,-	5
6003-000196	OPE	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	5
6003-000196	MAINLINE	SCREW-TAPTYPE;PWH,+,B,M3,L10,NI PLT,SWRCH18A	9


### 3.3 Disassembly procedure

#### 3.3.1 Cover

1. Remove the cassette.



3. Remove the front cover by releasing both hooks.



2. Open the front cover. Remove the toner cartridge.




4. To remove the top cover, first, remove 2 screws.




## 3. Disassembly and Reassembly

5. Open the rear cover. Remove 2 screws.




7. Lift up and release the top cover.



6. Unplug a connector on the main board.




8. Close the rear cover. Remove the duplex unit.




## 3. Disassembly and Reassembly


9. Remove the rear cover by releasing both hooks.



11. Remove 1 screw.  
Remove the right cover by releasing hooks.



10. Remove the left cover by releasing hooks.






### 3. Disassembly and Reassembly


#### 3.3.2 Main board

1. Remove the right cover. (Refer to 3.3.1 Cover)
2. Unplug all connectors on the main board.
3. Remove 4 screws.
4. Release the main board.



#### 3.3.3 HVPS board

1. Remove the right cover. (Refer to 3.3.1 Cover)
2. Remove 5 screws.
3. Unplug all connectors on the HVPS board.
4. Release the HVPS board.






## 3. Disassembly and Reassembly


### 3.3.4 SMPS board

1. Remove the right cover. (Refer to 3.3.1 Cover)
2. Unplug all connectors on the SMPS board.
3. Remove 4 screws.
4. Release the SMPS board.



### 3.3.5 Laser Scanning Unit (LSU)

1. Remove the top cover. (Refer to 3.3.1 Cover)
2. Unplug 2 at cables from the LSU.
3. Remove 3 screws.
4. Release the LSU.




### 3.3.6 Fuser unit


#### CAUTION

The temperature gets high in the vicinity of the fuser unit. When replacing it, you may get burned. Before replacing it, make sure that fuser unit has cooled.

1. Open the Frame-Rear by pushing both green points.



2. Remove the Frame-Rear by releasing both hooks.




3. Remove the exit sensor holder after removing 2 screws.

4. Remove 4 screws.

#### CAUTION



When reassembling the fuser unit, do not forget to tighten these screws.

5. Release the fuser unit.




### 3.3.7 Main drive unit

1. Remove the left cover. (Refer to 3.3.1 Cover)
2. Remove the Bar coupler.
4. Unplug the connector from the main motor.
5. Release the main drive unit.



3. Remove the main drive unit after removing 6 screws.




#### NOTE

When reassembling the main drive unit, tighten 6 screws in order as shown above.


### 3.3.8 Feed drive unit

1. Remove the main drive unit. (Refer to 3.3.7)
2. Release the feed drive unit after removing 2 screws.



### 3.3.9 Pick up/ Regi/ MP clutch


1. Remove the feed drive unit.
2. For the clutch to require replacement, unplug the connector then replace it.







### 3.3.10 Pick up roller

1. Remove the cassette and duplex unit.
2. Pull the small tap down, then release the pick up roller.



### 3.3.11 Transfer roller

1. Remove the top cover. (Refer to 3.3.1 Cover)
2. Release the LSU bracket after removing 4 screws.
3. Push the transfer roller holder to the center and release it.
4. Remove the transfer roller.




### 3.3.12 MP unit

1. Remove the front / top / right cover.

2. Remove 4 screws.




3. Separate the MP lower from the MP upper.




### 3.3.13 OPE board

1. Remove the top cover. (Refer to 3.3.1 Cover)
2. Release the OPE board after removing 4 screws.




### 3.3.14 Bin-full sensor

1. Remove the top / left cover. (Refer to 3.3.1 Cover)
2. Release the bin-full sensor after unplugging the connector.




### 3.3.15 Regi. / Feed / Empty sensor


1. Remove the cassette and duplex unit.
2. Remove the PLATE-FRAME BOTTOM after removing 4 screws.




3. Remove the sensor cover after removing 2 screws.



4. For the sensor to require replacement, unplug the connector then replace it.




5. Remove the sensor cover after removing 2 screws.






## 3. Disassembly and Reassembly

6. Unplug the connector then release the empty sensor.




### 3.3.16 Cassette roller (Retard roller)

1. Remove the cassette.  
2. Open the COVER-CASSETTE.



3. Release the Retard roller.




## 4. Alignment and Troubleshooting





### 4.1 Alignment and Adjustments

This chapter describes the main functions for service, such as the product maintenance method, the test output related to maintenance and repair, Jam removing method, and so on. It includes the contents of manual.


#### 4.1.1 Control Panel







##### ■ Type A




1	Eco	Enters eco printing mode to reduce toner consumption and paper usage.
2	 (Cancel)	Stops an operation at any time and there are more functions. • Printing demo page : Press and hold this button for about 5 seconds until the status LED blinks slowly, and release. • Printing con guration sheets : Press and hold this button for about 3 seconds until the status LED blinks quickly, and release.
3	 (Power)	You can turn the power on and off with this button.
4	 (Jam LED)	Shows the status of jam occurrence of your machine.
5	 (Status LED)	Shows the status of your machine.








## ■ Type B



1	<b>Display</b>	Shows the current status and prompts during an operation.
2	 <b>(Menu)</b>	Enters menu mode and scrolls through the available menus.
3	<b>OK</b>	Confirms the selection on the display.
4	 <b>(Back)</b>	Sends you back to the upper menu level.
5	<b>Eco</b>	Enters eco printing mode to reduce toner consumption and paper usage
6	 <b>(Cancel)</b>	Stops an operation at any time and there are more functions.
7	 <b>(Power)</b>	You can turn the power on and off with this button.
8	 <b>(Status LED)</b>	Shows the status of your machine.
9	 <b>(Jam LED)</b>	Shows the status of jam occurrence of your machine.
10	<b>Arrows</b>	Navigates available values by moving to the next or previous options.

## ■ Type C



1	<b>Display</b>	Shows the current status and prompts during an operation.
2	 <b>(Menu)</b>	Enters menu mode and scrolls through the available menus.
3	<b>OK</b>	Confirms the selection on the display.
4	 <b>(Back)</b>	Sends you back to the upper menu level.
5	<b>Eco</b>	Enters eco printing mode to reduce toner consumption and paper usage
6	 <b>(Cancel)</b>	Stops an operation at any time and there are more functions.
7	 <b>(Power)</b>	You can turn the power on and off with this button.
8	 <b>(Status LED)</b>	Shows the status of your machine.
9	 <b>(Wireless LED)</b>	Shows the current status of the wireless network connection.
10	 <b>(WPS)</b>	If your wireless access point supports Wi-Fi Protected Setup™ (WPS), you can configure the machine easily without a computer.
11	<b>Arrows</b>	Navigates available values by moving to the next or previous options.

### 4.1.2 Understanding The Status LED

The color of the Status indicates the machine's current status.

STATUS		DESCRIPTION
Off		<ul style="list-style-type: none"> <li>The machine is off-line.</li> </ul>
Green	Blinking	<ul style="list-style-type: none"> <li>When the backlight slowly blinks, the machine is receiving data from the computer.</li> <li>When the backlight blinks rapidly, the machine is printing data.</li> </ul>
	On	<ul style="list-style-type: none"> <li>The machine is on-line and can be used.</li> <li>The machine is in power saver mode.</li> </ul>
Red	Blinking	<ul style="list-style-type: none"> <li>A minor error has occurred and the machine is waiting for the error to be cleared. Check the display message. When the problem is cleared, the machine resumes.</li> <li>Small amount of toner is left in the cartridge. The estimated cartridge life of toner is close. Prepare a new cartridge for replacement. You may temporarily increase the printing quality by redistributing the toner.</li> </ul>
	On	<ul style="list-style-type: none"> <li>A toner cartridge has almost reached its estimated cartridge life<sup>a</sup>.</li> <li>The cover is opened. Close the cover.</li> <li>There is no paper in the tray. Load paper in the tray.</li> <li>The machine has stopped due to a major error.</li> </ul>
Orange	On	A paper jam has occurred
Blue <sup>b</sup>	On	When the machine is connected to a wireless network, Wireless LED lights on blue.

a. Estimated cartridge life means the expected or estimated toner cartridge life, which indicates the average capacity of print-outs and is designed pursuant to ISO/IEC 19752. The number of pages may be affected by operating environment, printing interval, graphics, media type and media size. Some amount of toner may remain in the cartridge even when red LED is on and the printer stops printing.

b. Wireless model only


### 4.1.3 JAM Removal

#### 4.1.3.1 Clearing paper jams


To avoid tearing the paper, pull the jammed paper out slowly and gently.

##### In tray 1

1. Open and close the front cover. The jammed paper is automatically ejected from the machine.  
If the paper does not exit, go to the next step.  
If the paper does not exit, go to the next step.
2. Pull out tray 1 .




3. Remove the jammed paper by gently pulling it straight out.



##### In optional tray2


1. Pull out optional tray 2.
2. Remove the jammed paper from the machine.



If the paper does not move when you pull or if you do not see the paper in this area, stop and go to the next step.

3. Pull tray 1 half-way out.


4. Pull the paper straight up and out.



5. Insert the trays back into the machine. Printing automatically resumes.

#### In the multi-purpose tray

1. If the paper is not feeding properly, pull the paper out of the machine.




2. Open and close the top cover to resume printing.




## 4. Alignment and Troubleshooting

## Inside the machine

1. Open the front cover and pull the toner cartridge out, lightly pushing it down.




2. Remove the jammed paper by gently pulling it straight out.



3. Replace the toner cartridge and close the front cover. Printing automatically resumes.


## In the exit area

1. Open and close the front cover. The jammed paper is automatically ejected from the machine. If you do not see the jammed paper, go to next step.
2. Gently pull the paper out of the output tray.



If you do not see the jammed paper or if there is any resistance when you pull, stop and go to the next step.


3. Open the rear cover.
4. Remove the jammed paper as shown in the following figure.




5. Close the rear cover. Printing automatically resumes.

**In the duplex unit area**

1. Pull the duplex unit out of the machine.




2. Remove the jammed paper from the duplex unit.



If the paper does not come out with the duplex unit, remove the paper from the bottom of the machine.


Insert the duplex unit into the machine.



If you still do not see the paper, go to the next step.

3. Open the rear cover.

4. Remove the jammed paper as shown in the following figure.



5. Return the fuser door and the lever to their original position.
6. Close the rear cover. Printing automatically resumes.

#### 4.1.4 Useful menu item for service

##### a) Monitoring the supplies life.

To view the supply life indicators, follow the steps below:

1. Press "menu" on the control panel.
2. Press System Setup > OK > Maintenance > OK.
3. Press Supplies Info > OK.
4. Press OK to select the option you want.

##### b) Printing a report

This product provides several printable reports for maintenance purposes. These reports can be used to aid the diagnosis of print quality problems.

###### ■ Demo page (Menu > Information > Demo page)

You can print the demo page to check whether your machine is printing properly or not.

###### ■ Configuration report (Menu > Information > Configuration)

You can print a report on the machine's overall configuration. It shows various SW version and current machine setting status.

###### ■ Supplies Information report (Menu > Information > Supplies Info.)

You can print supplies' information page. It shows consumable unit life status and toner using status.

###### ■ Usage Counter (Menu > Information > Usage Counter)

You can print a usage page. The usage page contains the total number of pages printed.

##### c) Maintenance menu.


This menu allows you to maintain your machine. (Menu > System setup > Maintenance)

- CLR Empty Msg. : This option appears only when toner cartridge is empty.
- Supplies Info. : This item allows you to check how many pages are printed and how much toner are left in the cartridge.
- TonerLow Alert : If toner in the cartridge has run out, a message informing user to change the toner cartridge appears. You can set the option for this message to appear or not.

**d) Altitude adjustment**

The print quality is affected by atmospheric pressure, which is determined by the height of the machine above sea level. The following information will guide you on how to set your machine to the best print quality or best quality of print.


Before you set the altitude value, determine the altitude where you are.



1. Ensure that you have installed the printer driver with the provided Printer Software CD.
2. Double-click the **Smart Panel** icon on the Notification Area in Linux. You can also click **Smart Panel** on the status bar in Mac OS X.  
For Windows user, select **Start > Programs or All Programs > Samsung Printers > Samsung Easy Printer Manager**.
3. Click **Printer Setting**.  
 If your machine is connected to the network, you can set the altitude via SyncThru™ Web Service.
4. Click **Setting > Altitude Adjustment**. Select the appropriate value from the drop-down list, and then click **Apply**.  
 You can also set the altitude in **System Setup > Altitude Adj.** option on the machine's display.

### 4.1.5 Periodic Defective Image

If an image defects appears at regular intervals on the printed-paper, it is due to a faulty or damaged roller. Refer to the table below and check the condition of the appropriate roller.



No	Roller Description	Band Period (mm)	Phenomenon	Defective part
1	1st Pressure roller		Background	Fuser unit
2	2nd Pressure roller		Background	
3	Heat roller		Black spot and fuser ghost	
4	Charge roller	26.7 mm	Black spot	Toner cartridge
5	Developer roller	36.78 mm	Horizontal band	
6	OPC drum	75.49 mm	White and Black spots	
7	Supply roller	69.57 mm	Horizontal band	
8	Transfer roller		Ghost, Damaged image	

### 4.1.6 Using the Easy Printer Manager program and smart panel

Smart Panel is a program that monitors and informs you of the machine status, and allows you to customize the machine's settings. Smart Panel is installed automatically when you install the machine software.

To use this program, you need the following system requirements:

- Windows. Check for windows operating system(s) compatible with your machine.
- Mac OS X 10.3 or higher
- Linux. Check for Linux systems that are compatible with your machine.
- Internet Explorer version 5.0 or higher for flash animation in HTML Help.

If you need to know the exact model name of your machine, you can check the supplied software CD.

#### 4.1.6.1 Using the Easy Printer Manager program (Windows only)


Easy Printer Manager is a Windows-based application that combines Samsung device settings into one location. Easy Printer Manager combines device settings as well as printing environments, settings/actions, launching applications, and so on. All of these features provide a gateway to conveniently use Samsung machine. Easy Printer Manager provides two different user interfaces for the user to choose from: the default user interface and the advanced settings user interface. Switching between the two interfaces is easy: just click a button.

#### Understanding Easy Printer Manager program



This interface is intended to be used by general device users in a small business or small home office environment.


For Windows user, select Start > Programs or All Programs > Samsung Printers > Samsung Easy Printer Manager.

The Easy Printer Manager interface is comprised of various basic sections as described in the table that follows.



## 4. Alignment and Troubleshooting


1	<b>Printer List</b>	The Printer List displays icons corresponding to discovered network or local printers' error status.
2	<b>Printer Information</b>	This area gives you general information about your machine. You can check information, such as the machine's model name, IP address (or Port name), and machine status.  Troubleshooting button: This button opens Troubleshooting Guide when an error occurs. You can directly open the necessary section in the user's guide.
3	<b>Application information</b>	Includes links for changing to the advanced settings, preference, help, and about.
4	<b>Quick links</b>	Displays Quick links to machine specific functions. This section also includes links to applications in the advanced settings.  If you connect your machine to a network, the SyncThru™ Web Service window appears.
5	<b>Contents Area</b>	Displays information about the selected machine, remaining toner level and paper. The information will vary based on the machine selected. Some machines do not have this feature.
6	<b>Order Supplies</b>	Click on the Order button from the supply ordering window. You can order replacement toner cartridge(s) from online.

 Click the Help button from the upper-right corner of the window and click on any option you want to know about.

#### 4.1.6.2 Using the Smart Panel program (Macintosh and Linux only)

Smart Panel is a program that monitors and informs you of the machine's status, and allows you to customize the machine's settings. For Macintosh, Smart Panel is installed automatically when you install the machine software. For Linux, you can download Smart Panel from the Samsung website.

##### Smart Panel overview



1	<b>Toner Level</b>	You can view the level of toner remaining in each toner cartridge. The machine and the number of toner cartridge(s) shown in the above window may differ depending on the machine in use. Some machines do not have this feature.
2	<b>Buy Now</b>	You can order replacement toner cartridge(s) from online.
3	<b>User's Guide</b>	You can view the online User's Guide.
4	<b>Printer Setting</b>	You can configure various machine settings in the Printer Settings Utility window. Some machines do not have this feature.



## 4.1.7 Updating Firmware

---

This chapter includes instructions for updating the printer firmware. You can update the printer firmware by using one of the following methods :

- Update the firmware by using the USB port.
- Update the firmware by using the network.

### 4.1.7.1 Update the firmware by using the USB port

---

#### [Upgrading preparations]

- usblast2.exe : Tool which sends firmware data to printer.
- Firmware file to upgrade

#### [Upgrade Procedure]

1. Turn the machine off.
2. Connect USB cable to printer.
3. Turn the machine on. Check if the printer is the ready status.
4. Drag the firmware file and Drop down on the usblast2.exe.  
And then firmware update will be started automatically.
5. When upgrading is completed, machine is automatically re-booting.


### 4.1.7.2 Update the firmware by using the network

#### [Upgrading preparations]

- Wired or Wireless Network connection is established
- Firmware file to upgrade


#### [Upgrade Procedure]

1. Open Web-browser and input IP address of machine. Click "Login".




2. Log-in Admin Mode

ID: admin, PW: sec00000




3. Select Maintenance menu and click "upgrade wizard"





## 4. Alignment and Troubleshooting


4. Select firmware file using “browser” button and press next button.



5. SyncThru will check verify firmware file and compare version and press next button.



6. Machine starts upgrading. SyncThru will return home page after upgrading is completed.



## 4.1.8 Tech Mode


### 4.1.8.1 Entering the Tech Mode

In service (tech) mode, the technician can check the machine and perform various test to isolate the cause of a malfunction. While in Tech mode, the machine still performs all normal operations.

**NOTE** - There is no tech mode for LED type model (ML-331xD,371xD)

To enter the Tech Mode

To enter the Tech Mode, press “ Menu + Back + Left + Right + OK + Cancel” in sequence



## 4.1.8.2 Tech Mode Menu

Depth 1	Depth 2	Depth 3	Depth 4
Data Setup	Counter Reset	Fuser	
		Pickup Roller	Tray 1
			Tray 2
			MP Tray
		Retard Roller	Tray1
			Tray2
	Transfer Level	Level 0 ~3	
	Density Level	Level 0 ~3	
	Toner Low Level	[1~30]: 10 %*	
	Paper Substitution	Off *	
		On	
Report	Supplies Info	Printing...	
	Event Log	Printing...	
	Job Duty Report	Printing...	
	Density Report	Printing...	
	Frame JIG	Printing...	
	Usage Counter	Printing...	
EDC Mode	NVM Read Write	103-Time	
		105-Duty	
		106-Deve	
		107-Transfer	
		109-Temp Offset	
		110-LD Power	
	NVM Initialize	Initialize Now	
	Test Routines	100-Motor	
		101-Clutch	
		102-Sensor	
		105-MHV Bias	
		106-Dev Bias	
		107-Transfer Bias	
		109-Fuser Heater	
		112-ACR	

### 4.1.8.3 Tech Mode Menu description

---

## 1) Data Setup

### Counter Reset

This menu can reset the counts for the Fuser or Pick up roller or Transfer roller. When replacing these parts, you must do this menu.

### Toner Low Level

When the toner remains less than setting up level, the machine notify user of toner low.

### Paper Substitution

Between A4 and Letter size paper, print job can be executed without paper mismatch message, when the setting value is "On".

## 2) Report

### Supplies Info

It shows consumable unit life status and toner using status.

### Event Log

It shows various kinds of errors which can be occurred in machine. It also store history error count how many errors are issued.

### Job Duty Report

It shows printing usage by print job duty.

### Density Report

It shows image density control history.

### Usage Counter

It contains the total number of pages printed.

### 3) EDC mode

#### NVRAM Read/Write

This menu can change a configuration value for engine firmware.

Code	LCD	Meaning	Default	Max/Min
103-0040	0040-Pick Int Delay	Change time interval for paper pick-up	0	0~100(*100msec)
103-0050	0050-Pick Spl Delay	Change time interval for paper pick-up	0	0~100(*100msec)
105-0030	0030-MHV DC K	Charger HV Black DC Duty	720	50~900
106-0030	0030-Deve DC K	Developer DC Black	431	50~900
107-0030	0030-THV K	Transfer1 HV Black Duty	520	50~900
109-0000	0000-Ready Temp	Target Temperature during standby mode.	10	0~15
109-0010	0010-Print Temp	Target Temperature during run mode.	5	0~10
109-0030	0030-101-185mm Temp	Offset temperature required on thermistor B for paper width.	5	0~15
109-0040	0040-186-216mm Temp	Offset temperature required on thermistor B for paper width.	5	0~15
109-0050	0050-60gms Temp	Media type offset for fuser roll temperature.	5	0~15
109-0060	0060-90gms Temp	Media type offset for fuser roll temperature.	5	0~10
109-0070	0070-Bond Temp	Media type offset for fuser roll temperature.	5	0~10
109-0080	0080-Trans Temp	Media type offset for fuser roll temperature.	5	0~10
109-0090	0090-CardStock Temp	Media type offset for fuser roll temperature.	5	0~10
109-0100	0100-Envelopes Temp	Media type offset for fuser roll temperature.	5	0~10
109-0110	0110-Labels Temp	Media type offset for fuser roll temperature.	5	0~10
110-0070	0070-LD Power K	Black LD Power at Normal Speed	470	50~900

#### Test Routines

This menu can perform the operation test for the main components.

Code	LCD	Meaning	State Displayed	Related Components
100-0000	Main BLDC Motor	Main BLDC Motor is On/Off	On[Off]	Engine
100-0010	Main BLDC Motor Ready	Detect if Main BLDC Motor runs at normal speed	High[Low]	Engine
100-0260	SMPS Fan Run	Start/Stop developer fan run	On[Off]	Engine
101-0000	Bypass Feed Clutch	Engages drive to pick up a paper from bypass Tray(MP Tray).	On[Off]	Engine
101-0010	T1 Pick-Up Clutch	Engages T1 pick up clutch from tray 1.	On[Off]	Engine
101-0020	T2 Pick-Up Clutch	Engages T2 pick up clutch from tray 2. (Optional)	On[Off]	Engine
101-0050	Registration Clutch	Engages drive to registration roller.	On[Off]	Engine
101-0190	Out-Bin Full Sensor	Detect when a paper is at Duplex Ready sensor.	High[Low]	Engine




## 4. Alignment and Troubleshooting

Code	LCD	Meaning	State Displayed	Related Components
102-0010	T1 Paper Empty Sensor	Detect when paper is in Tray1.	High[Low]	Engine
102-0080	T2 Paper Empty Sensor	Detect when paper is in tray2.	High[Low]	Engine
102-0280	Bypass Paper Empty Sensor	Detects when paper is in Bypass Tray(MP Tray).	High[Low]	Engine
102-0290	Feed Sensor	Detect when a paper is at Feed sensor.	High[Low]	Engine
102-0300	T2 Feed Sensor (or Door Open)	Detect when a paper is at T2 Feed sensor. (optional)	High[Low]	Engine
102-0360	Regi. Sensor	Detect when a paper is at Regi. sensor.	High[Low]	Engine
102-0370	Exit Sensor	Detect when a paper is at Exit. sensor.	High[Low]	Engine
105-0030	Black MHV Bias	Black MHV bias voltage on at normal drive level	On[Off]	Engine
106-0030	Black Dev Bias	Black Dev bias voltage on at normal drive level	On[Off]	Engine
107-0030	Black THV Bias	Black THV bias voltage on at normal drive level	On[Off]	Engine
107-0031	Black THV(-) Bias	Black THV bias voltage on at normal drive level	On[Off]	Engine
107-0070	Black THV Bias Read	Detect what the THV value is on the THV Roller	Numeric 3 digits	Engine
109-0000	Fuser Temperature A	Detects what the temperature A is on fuser.	Numeric 3 digits	Engine
109-0040	Fuser Fan Run	Fuser Fan Motor On/Off	On[Off]	Engine
109-0050	Fuser Bias	Fuser bias voltage on at normal drive level	On[Off]	Engine
110-0000	LSU Motor1 Run Ready	Detects if LSU motor1 runs at normal speed.	High[Low]	Engine
110-0060	LSU Motor1 Run	LSU Motor1 On/Off	On[Off]	Engine
110-0110	LSU LD Power4	LSU LD4 Power On/Off (black)	On[Off]	Engine

## 4.2 Troubleshooting

### 4.2.1 Procedure of Checking the Symptoms

Before attempting to repair the printer, first obtain a detailed description of the problem from the customer.



#### 4.2.1.1 Basic Check List

##### 1. Check the Power.

- Check that the power switch is turned on.
- Check that the power cable is plugged into the outlet and the printer.
- Check the voltage of the power outlet.

##### 2. Check the LED of Panel.

- Is there OPE LED ON?  
--> If not check power cable, switch SMPS or Main board.
- Is the abnormal Lamp?  
--> Check the main PBA and cable harness.

##### 3. Check the Paper Path

- Is there a Paper Jam?  
--> Remove any paper fragments caught in the paper path.
- Paper Jam occurs repeatedly at a specific point in the Paper Path  
--> Open the fuser cover, Jam clear.  
--> Dismantle the machine and carefully inspect the region where the jam occurs.  
(Especially, check if paper fragments are caught in the Fuser)

##### 4. Print the Information Page (Configuration).

- Try printing a test page from a computer.  
--> If there is an error check cables and driver installation.

##### 5. Check the Print Quality.

- Is there are a Print Quality Problem?  
--> Refer to the image quality problem.

##### 6. Check consumables (toner etc.).

- Using the keys print the Test Pattern.  
--> Expected life of various consumable parts, compare this with the figures printed and replace as required

### 4.2.1.2 Initial Inspection

#### 1. Check Power part

1. The printer does not work no matter how long you wait.
  - A. Is the Power Switch (printer and wall socket) turned on ?
  - B. Is the Power Cord connected to the printer correctly ?
  - C. Is the Power cord connected to the wall socket correctly ?
  - D. Is wall socket working ?
  - E. Is the unit rated at the same voltage as the supply ?
2. Does the Fan work when power is turned on?
  - A. Check the connectors on the SMPS.
  - B. Check the fuses in the SMPS.

#### 2. Check the Installation Environment.

1. Ensure the installation surface is flat, level and free from vibration.  
If necessary move the printer.
2. Ensure that the temperature and humidity of the surroundings are within specification  
If necessary move the printer.
3. Ensure that the printer is positioned away from any air conditioning or other heating or cooling equipment.  
Also ensure that it is not positioned in a direct draft from any air conditioning, fan or open window.  
If necessary move the printer.
4. Ensure the printer is not positioned in direct sunlight.  
If it is unavoidable use a curtain to shade the printer.
5. Ensure the printer is installed in a clean dust free environment.  
Move the printer to clean area if necessary.
6. Some industrial or cleaning processes give off fumes which can affect the printer.  
Move the printer away from this type of air pollution

#### 3. Check paper type.

1. Use only paper which is of a suitable quality, weight and size?  
See the user guide.

#### 4. Check the overall condition of the printer

1. Is the printer properly maintained ?  
Clean the Paper Transport Passages.  
Any rollers with dirt surfaces should be cleaned or replaced.

## 4.2.2 Error Message and Troubleshooting

Messages appear on the Smart Panel program window or on the control panel to indicate machine status or errors. Refer to the tables below to correct the problem.

Error Code	Error Message	Troubleshooting Page
A1-1110	Error #A1-1110: Turn off then on.	26 page
C1-1110 C1-1120 C1-1140	Prepare new cartridge Replace new cartridge Replace new cartridge	27 page
C1-1411	Install toner	28 page
C1-1512	Not Compatible Toner cartridge.	28 page
H1-1210	Paper jam in Tray2.	29 page
H1-1252	Paper is empty in Tray2.	29 page
M1-1110	Paper Jam in Tray1.	30 page
M1-1610	Paper Jam in MP tray.	30 page
M1-5112	Paper is empty in tray 1.	31 page
M1-5612	Paper Empty in MP Tray.	32 page
M2-1110	Paper Jam inside machine.	33 page
M2-2110	Paper Jam inside machine.	34 page
M2-2310	Paper Jam bottom of duplex.	34 page
M3-1110	Paper Jam in exit area.	35 page
M3-2130	Output bin full. Remove paper.	35 page
S2-4110	Door open. Close it.	36 page
S6-3123	Network Problem: IP Con ict.	37 page
S6-3128	802.1x Network Error.	37 page
U1-2320	Error #U1-2320 Turn off then on.	38 page
U1-2330	Error #U1-2330 Turn off then on.	38 page
U1-2340	Error #U1-2340 Turn off then on.	39 page
U2-1111 U2-1113	Error #U2-1111 Turn off then on. Error #U2-1113 Turn off then on.	40 page

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b> A1-1110</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Error #A1-1110: Turn off then on.</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> After working the main BLDC motor, the Ready signal has not occurred within 1 sec.</li> </ul> <ol style="list-style-type: none"> <li>1. Harness is defective. Connector is not connected properly.</li> <li>2. OPC coupler in the toner cartridge has overloaded.</li> <li>3. Main BLDC motor is defective.</li> <li>4. Engine board is defective.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method :</b></li> </ul> <p>※ First, turn the machine off then on. If the error persists, refer to the following.</p> <ol style="list-style-type: none"> <li>1. Check if the motor connector is connected properly. Reconnect it.</li> <li>2. OPC coupler has overloaded. After removing the toner cartridge, rotate the OPC coupler. (Spec : 6 kgf.cm) If there is any damage, the OPC coupler can't rotate well. Replace the toner cartridge.</li> <li>3. The main BLDC motor is defective. <ul style="list-style-type: none"> <li>- Unplug the connector from the motor carefully.</li> <li>- Replace the main BLDC motor with new one.</li> </ul> </li> </ol> <div data-bbox="162 1261 932 1834"> </div> <ol style="list-style-type: none"> <li>4. If the problem persists, replace the main board.</li> </ol>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b> C1-1110 / C1-1120 / C1-1140</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Prepare new cartridge / Replace new cartridge / Replace new cartridge</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> The remaining toner cartridge is less than 10% The toner cartridge is at the end of its life.</li> </ul>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b>  1. Print the supply information report. Check the life remaining of the toner cartridge. If its life is at the end, turn the machine off and replace the toner cartridge with new one.</li> </ul> <div data-bbox="173 786 1276 1200"> </div>	



## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b> C1-1411</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Install toner.</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> The toner cartridge is not installed.</li> </ul>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b>  1. Turn the machine off then on.  2. Remove the toner cartridge. Thoroughly roll the cartridge five or six times to distribute the toner evenly inside the cartridge. And reinstall the toner cartridge.</li> </ul>	

<ul style="list-style-type: none"> <li>• <b>Code</b> C1-1512</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Not Compatible Toner cartridge.</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> Toner cartridge is not compatible.</li> </ul>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b>  1. Print the supply information report. Check information of the toner cartridge.  2. If the toner cartridge is not a Samsung genuine toner cartridge, replace with new one.</li> </ul>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> H1-1210	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Paper jam in Tray2.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>A paper jam was detected in the feed area of the tray2.</p> <ol style="list-style-type: none"> <li>1. Paper was inserted abnormally or was not loaded in the cassette properly.</li> <li>2. Pick Up unit has a problem.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Open the Tray2 and remove the jammed paper.</li> <li>2. If there is any defective part in the pick up unit, replace it.</li> </ol>	


<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> H1-1252	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Paper is empty in Tray2.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>Paper is empty in Tray2. The status LED is red.</p> <ol style="list-style-type: none"> <li>1. There is no paper in the tray2.</li> <li>2. Actuator-Paper Empty is defective.</li> <li>3. Photo Sensor is defective or connection is bad.</li> <li>4. Main Board is defective.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Load the paper in the tray2.</li> <li>2. If the Actuator-Paper Empty is defective, replace it.</li> <li>3. If the Photo Sensor is defective, replace it. Check if the connector is connected properly.</li> <li>4. If the problem persists, replace the Main Board.</li> </ol>	

## 4. Alignment and Troubleshooting


<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> M1-1110	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Paper Jam in Tray1.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>The jammed paper has occurred in the tray1.</p> <ol style="list-style-type: none"> <li>1. Pick-Up or Torque Limiter Roller is contaminated or worn out.</li> <li>2. There is some obstacles in the paper path.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Clear the jammed paper. If the problem persists, check the following.</li> <li>2. While pushing the Paper Empty Sensor, send the printing data. Check if the pick up roller is rotating normally.</li> <li>3. Check if there is any obstacles in the paper path (from Pick-Up to Feed Sensor). The feed roller should be especially checked.</li> <li>4. Print out the Supplies Information. Check the Tray 1 Roller Life and Tray1 Torque Limiter Life. If the life came to the end, replace the relative roller.</li> </ol>	

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> M1-1610	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Paper Jam in MP tray.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>The jammed paper has occurred in the MP tray.</p> <ol style="list-style-type: none"> <li>1. MP Pick-Up or MP Torque Limiter Roller is contaminated or worn out.</li> <li>2. There is some obstacles in the paper path.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Clear the jammed paper. If the problem persists, check the following.</li> <li>2. While pushing the Paper Empty Sensor, send the printing data. Check if the pick up roller is rotating normally.</li> <li>3. Check if there is any obstacles in the paper path (from Pick-Up to Feed Sensor). The feed roller should be especially checked.</li> <li>4. Print out the Supplies Information. Check the Tray Roller Life and Tray Torque Limiter Life. If the life came to the end, replace the relative roller.</li> </ol>	


## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>M1-5112</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Paper is empty in tray 1.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>Paper is empty in Tray1. The status LED is red.</p> <ol style="list-style-type: none"> <li>1. There is no paper in the tray1.</li> <li>2. Actuator-Paper Empty is defective.</li> <li>3. Photo Sensor is defective or connection is bad.</li> <li>4. Main Board is defective.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Load the paper in the tray1.</li> <li>2. If the Actuator-Paper Empty is defective, replace it.</li> <li>3. If the Photo Sensor is defective, replace it. Check if the connector is connected properly.</li> </ol>	
	
<ol style="list-style-type: none"> <li>4. If the problem persists, replace the Main Board.</li> </ol>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>M1-5612</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Paper Empty in MP Tray.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>Paper is empty in MP Tray. The status LED is red.</p> <ol style="list-style-type: none"> <li>1. There is no paper in the MP tray.</li> <li>2. Actuator-Paper Empty is defective.</li> <li>3. Photo Sensor is defective or connection is bad.</li> <li>4. Main Board is defective.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Load the paper in the MP tray.</li> <li>2. If the Actuator-Paper Empty is defective, replace it.</li> <li>3. If the Photo Sensor is defective, replace it. Check if the connector is connected properly.</li> </ol> <div data-bbox="161 1001 769 1453">  </div> <ol style="list-style-type: none"> <li>4. If the problem persists, replace the Main Board.</li> </ol>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>M2-1110</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Paper Jam inside machine.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>A paper jam was detected at the feed sensor.</p> <ol style="list-style-type: none"> <li>1. The feed sensor is defective.</li> <li>2. The Regi Roller was contaminated or worn out.</li> <li>3. There is some obstacles in the paper path.</li> <li>4. The driving for the toner cartridge has some problem.</li> <li>5. The driving for the fuser unit has some problem.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Remove the jammed paper. If the error persists, check the followings.</li> <li>2. Check if the feed sensor connector is connected properly.</li> </ol>  <ol style="list-style-type: none"> <li>3. Check if the Regi roller is contaminated or worn out. If yes, replace it.</li> <li>4. Check if there is any obstacles or contamination in the paper path. If yes, clean or remove it.</li> </ol>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>M2-2110</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Paper Jam inside machine.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>A paper jam was detected in the duplex area.</p> <ol style="list-style-type: none"> <li>1. The printed image is skewed.</li> <li>2. The duplex unit is not installed or the installation is wrong.</li> <li>3. There is some obstacles in the paper path.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Remove the jammed paper.</li> <li>2. Remove the contamination or obstacles in the paper path.</li> <li>3. Check if the duplex unit is installed properly.</li> </ol>	

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>M2-2310</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Paper Jam bottom of duplex.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>A paper jam was detected in the bottom of duplex.</p> <ol style="list-style-type: none"> <li>1. There is some obstacles in the paper path.</li> <li>2. The paper guide in the tray was not adjusted properly.</li> <li>3. The exit sensor was not assembled properly.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Remove the jammed paper.</li> <li>2. Remove the contamination or obstacles in the paper path.</li> <li>3. Adjust the paper guide properly.</li> <li>4. Check if the exit sensor is assembled properly. Reassemble it.</li> </ol>	



## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b> M3-1110</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Paper Jam in exit area.</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> A paper jam was detected in the exit area.</li> </ul> <ol style="list-style-type: none"> <li>1. There is some obstacles in the paper path.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Remove the jammed paper.</li> <li>2. Check if there is any obstacles or contamination in the paper path. If yes, clean or remove it.</li> </ol>	

<ul style="list-style-type: none"> <li>• <b>Code</b> M3-2130</li> </ul>	<ul style="list-style-type: none"> <li>• <b>Error message</b> Output bin full. Remove paper.</li> </ul>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b> The machine detected that the output tray has got full or the bin-full sensor is defective.</li> </ul> <ol style="list-style-type: none"> <li>1. Output tray is full.</li> <li>2. Outbin full sensor connection is wrong.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Remove the paper on the output tray. (The maximum loading capacity is 150 sheets based on standard paper(80g/m2).)</li> <li>2. Check if the Bin-full Sensor connector is connected properly. Reconnect it or replace the Bin-full sensor.</li> </ol>	
	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>S2-4110</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Door open. Close it.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>Door is open or the cover open switch is defective. The status LED is red.</p>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Check if the front door is closed correctly.</li> <li>2. Check if the rear door is closed correctly.</li> <li>3. Check if the connection between the main board and HVPS board is correct.</li> <li>4. Check if the cover open switch on HVPS board is operated properly. If it is defective, replace the HVPS board.</li> </ol> <div data-bbox="162 965 876 1420"> </div>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>S6-3123</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Network Problem: IP Conflict.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>Network has some problem.</p> <ul style="list-style-type: none"> <li>- IP address conflicts with that of other system.</li> <li>- Communication error</li> <li>- There is no response when checking the ping test.</li> </ul>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <p>Change the machine's IP address.</p> <ul style="list-style-type: none"> <li>- Set-up the IP address in this order, Network -&gt; TCP/IP (IPv4) -&gt; STATIC.</li> <li>- In case of DHCP or Bootp, reboot the machine to receive a new IP address.</li> </ul>	

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>S6-3128</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>802.1x Network Error.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>802.1x Network Error</p> <ul style="list-style-type: none"> <li>- The connection was requested for wired port, the server has rejected.</li> <li>- The connection protocol is not the same or user information (ID/Password) is wrong.</li> </ul>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <p>Check the setting-up for 802.1x connection server.</p> <ul style="list-style-type: none"> <li>- Re-enter the server information and connection protocol.</li> <li>- Re-enter the user information.</li> </ul>	

## 4. Alignment and Troubleshooting





<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> U1-2320	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Error #U1-2320 Turn off then on.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> The temperature control of fuser unit is abnormal. (Open Heat Error)	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Turn the machine off. Re-install the fuser unit. Then turn the machine on. Is the error message is disappeared?</li> <li>2. If the problem persists, turn the machine off and remove the fuser unit. Check if the fuser connector is connected properly. Check if the input voltage is normal.</li> </ol>	

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> U1-2330	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> Error #U1-2330 Turn off then on.
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> The temperature control of fuser unit is abnormal. (Low Heat Error)	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Turn the machine off. Re-install the fuser unit. Then turn the machine on. Is the error message is disappeared?</li> <li>2. If the problem persists, turn the machine off and remove the fuser unit.               <ol style="list-style-type: none"> <li>a. Check if the fuser connector is connected properly.</li> <li>b. Check if the input voltage is normal.</li> <li>c. Check if the thermistor is twisted or contaminated.</li> </ol> </li> </ol>	

## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>U1-2340</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Error #U1-2340 Turn off then on.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>The temperature control of fuser unit is abnormal. (Over Heat Error)</p>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Turn the machine off. Re-install the fuser unit. Then turn the machine on. Is the error message is disappeared?</li> <li>2. If the problem persists, turn the machine off and remove the fuser unit.               <ol style="list-style-type: none"> <li>a. Check if the fuser connector is connected properly.</li> <li>b. Check if the input voltage is normal.</li> <li>c. Check if the thermistor is twisted or contaminated.</li> </ol> </li> </ol>	


## 4. Alignment and Troubleshooting

<ul style="list-style-type: none"> <li>• <b>Code</b></li> </ul> <p>U2-1111 / U2-1113</p>	<ul style="list-style-type: none"> <li>• <b>Error message</b></li> </ul> <p>Error #U2-1111 Turn off then on. / Error #U2-1113 Turn off then on.</p>
<ul style="list-style-type: none"> <li>• <b>Symptom / Cause</b></li> </ul> <p>LSU Motor does not work normally.</p> <ol style="list-style-type: none"> <li>1. Harness connection error.</li> <li>2. LSU is defective.</li> <li>3. Main board is defective.</li> </ol>	
<ul style="list-style-type: none"> <li>• <b>Troubleshooting method</b></li> </ul> <ol style="list-style-type: none"> <li>1. Execute the LSU motor test in EDC mode. Check LSU motor operation sound.</li> <li>2. If there is no sound, remove the right cover. Check if the LSU harness is connected on the main board properly. (picture-①)</li> <li>3. If it is OK, remove the top cover. Check if the LSU harness is connected on LSU board properly. (picture- ②,③)</li> <li>4. Check if the LSU harness is defective. (picture-④)</li> <li>5. Reconnect the LSU harness and then execute the LSU motor test again.</li> <li>6. If the problem persists, replace the LSU.</li> <li>7. If the problem persists after replacing LSU, replace the main board.</li> </ol>	
 	 

### 4.2.3 Image Quality problem

#### 1) Vertical Black Line and Band


**Description :** 1. Straight thin black vertical line occurs in the printing.  
2. Dark black vertical band occur in the printing.







## 2) Vertical White Line

Description : White vertical voids in the image.





### 3) Horizontal Black Band

**Description :** Dark or blurry horizontal stripes occur in the printing periodically.  
(They may not occur periodically.)




## 4) Black/White Spot

Description : 1. Dark or blurry spots occur periodically in the printing  
2. White spots occur periodically in the printing




## 5) Light Image

Description : The printed image is light, with no ghost.




## 6) Dark Image or a Black Page

Description : The printed image is dark.





## 7) Uneven Density

Description : Print Density is uneven between left and right.



## 8) Background


Description : Light dark background appears in whole area of the printing.







## 9) Ghost

Description : Ghost occurs at 94.4 mm intervals of the OPC drum in the whole printing.





## 10) Stains on the Face of Page

Description : The background on the face of the printed page is stained.




## 11) Stains on Back of Page

Description : The back of the page is stained at 47 mm intervals.



## 12) Blank Page Print out


Description : Blank page is printed.



## 4.2.4 Other errors


### 1) Multi-Feeding

Description : Multiple sheets of paper are fed at once.



## 2) No Power

Description : When system power is turned on, all lamps on the operator panel do not come on.



## 4.2.5 Network problems and solutions

Before Troubleshooting, check below check point.

Check Point	Action
LAN cable check	A. Connected or Not connected B. Wrong cable (defected cable, crossover cable) C. Connection connector (Link partner check)
Network LED check	A. Link LED check (Link LED On when connected) B. Activity LED check (No packet Regularly blinking, packet random blinking depend on Printer Model)
Print Network test page	A. Printed correctly. If not, NIC is in lock up state or NIC can not communicate with printer B. Network address value check : IP address, Subnet Mask, Gateway, MAC address C. NIC F/W version (Correct or not) 1) V1.0x.xx : NPC3 2) V2.0x.xx : NPC3H 3) V3.0x.xx : PHY Board 4) V4.0x.xx : On Board D. Protocol Enable / Disable E. WLAN module / Status check if WLAN available.
Printer SET status check	A. Toner Empty, Paper Empty and so on : Hard Stop cases (Job can be nished completely)

### Network Printer Configuration check

- Address Con ict check
  - IP address Con ict : Same IP address in a network
    - Unplug network cable and PING test
  - MAC address Con ict : Same MAC address in a physical network
    - Default MAC address or same MAC address (PING and ARP -a)
- IP get method check (Panel or SWS)
  - DHCP/BOOTP : IP can be changed after rebooting
  - Auto IP address : DHCP is on as default.
- Protocol Enable / Disable, Port Number (In SWS)
- IP ltering On/Off
- SNMP community name check (When SNMP no response)




## Host PC Configuration check

1. Address Conflict check
  - A. IP address Conflict : Same IP address in a network
    - Unplug network cable and PING test at other PC
2. Protocol Enable / Disable, Port Number in printer driver

## Factory Default


1. Network Value changed to default value
  - A. Some of Network value will not be changed immediately.
  - B. Factory default operation will be done after Power Off / Power On

### **5.1 Block Diagram(ML-331x series)**




## 5. System Diagram

## Block Diagram(ML-371x series)



## 5. System Diagram

## 5.2 Connection Diagram(ML-371x series)





## 6. Reference Information


This chapter contains the tools list, list of abbreviations used in this manual, and a guide to the location space required when installing the printer. A definition of test pages and Wireless Network information definition is also included.

### 6.1 Tool for Troubleshooting

The following tools are recommended safe and easy troubleshooting as described in this service manual.


- **DVM (Digital Volt Meter)**

Standard : Indicates more than 3 digits.



- **Driver**

Standard : “-” type, “+” type (M3 long, M3 short, M2 long, M2 short).



- **Tweezers**

Standard : For general home use, small type.




- **Cotton Swab**

Standard : For general home use, for medical service.




- **Cleaning Equipments**

Standard : An IPA (Isopropyl Alcohol) dry wipe tissue or a gentle neutral detergent and lint-free cloth.



- **Vacuum Cleaner**




- **Spring Hook**

Standard : For general use



- **Software (Driver) installation CD ROM**



## 6.2 Acronyms and Abbreviations

The table below explains abbreviations used in this service manual.

The contents of this service manual are declared with abbreviations in many parts. Please refer to the table.

### 6.2.1 Acronyms

ABS	Automatic Background Suppression(a kind of copy feature)	FDI	Foreign Device Interface
APF	Automatic Paper Feeder(Tray)	FIA	Foreign Interface Attachment
BOOTP	BOOTSTRAP PROTOCOL	FRU	Field Replaceable Unit
CCD	Charged Coupled Device	FPOT	First Print Out Time
CIS	Contact Image Sensor	GW	GateWay
CPM	Copies Per Minute	HH	High Temperature, High Humidity (Testing Chamber conditions)
CP	Control Panel(= OPE)	HPVC	Halftone Printing Video Controller in the SPGPm (Graphic Processor for Copy)
CQ	Copy Quality	IDC	International Data Corp.
CRU	Customer Replaceable Unit	IMAP	Internet Message Access Protocol
CRUM	CRU Memory	IPP	Internet Printing Protocols
CW	Center Ware	IPM	Images Per Minutes
CWDP	Center Ware Device Discovery Software(Samsung equivalent of Samsung's SyncThru)	IPX	Internetwork Packet Exchange
CWIS	Center Ware Internet Services	IQ	Image Quality
DADF	Duplex Auto Document Feeder (= DADH)	ITU	International Telecommunication Union
DC	Direct Connect	JBIG	Joint Binary Image Group (a kind of image data coding method)
DDNS	Dynamic Domain Name System	JPEG	Joint Photographic Expert Group (a kind of image data coding method)
DHCP	Dynamic Host Configuration Protocol	LCD	Liquid Crystal Display
DLC	Data Link Control	LEF	Long Edge Feeding
DNS	Domain Name System	LL	Low Temperature, Low Humidity (Testing Chamber conditions)
ECM	Error Correction Mode	LPR/LPD	Line Printer Daemon Protocols (LPR is a TCP-based protocol)
ECP	Enhanced Capability Port	LSU	Laser Scanning Unit
e-Coil	Extended Coil technology for Rapid(Fast) Fusing.	LUI	Local User Interface
EH&S	Samsung Environment, Health, & Safty	MCBF	Mean Copy Between Failure
ESMTP	Extended Simple Mail Transfer Protocol	MDSP	Multiple Document Single Printout
EP	Electro Photography	MFP	Multi-Functional Product
EPC	Electric Pre-Collation	MH	Modified Huffman (a kind of image data coding method)
FCOT	First Copy Out Time		

## 6. Reference Information

MIB	Management Information Base	RT-OS	Real Time Operating System
MIME	Multipurpose Internet Mail Extensions	RX	Receive
MR	Modified Read (a kind of image data coding method)	S2E	Scan-To-Email
MMR	Modified and Modified Read (a kind of image data coding method)	SAD	Solid Area Density
MN std	Multi-National Standard	SC	Service Call
MSOK	Master SOK(System Operation Key)	SCF	Second Cassette Feeder
MSO	Mixed Size Original	SDSP	Single Document Single Printout
MP	Multi Purpose	SDMP	Single Document Multiple Printout
MPBF	Mean Print Between Failure	SDR	Shut Down Rate
MSI	Multi Sheet Input	SEF	Short Edge Feeding
MTBF	Mean Time Between Failure	SIR	Standard (or Standard) Image Reference
MTTR	Mean Time To Repair	SOK	System Operation Key
NCP	Network Control Protocol	sRGB	Standard RGB (Color Coordinate System)
NIC	Network Interface Card	SNMP	Simple Network Management Protocol
NOS	Network Operating System	TCP/IP	Transmission Control Protocol/Internet Protocol
NN	Normal Temperature, Normal Humidity (Testing Chamber conditions)	TBC(or tbc)	To Be Continued
NSDR	Non-Shut Down Rate(=USDR)	TBD(or tbd)	To Be Determined
NW	Network	TIFF	(Adobe & Aldus) Tagged Image File Format
OD	Optical Density	TRIM	Technical Retro fit Interim Maintenance
OHD	On Hook Dial	TTM	Time to Market
OSOK	Optional SOK(System Operation Key)	TX	Transmit
OP	Operational Procedure	UI	User Interface
PCL	Printer Control Language	UMC	Unit Manufacturing Cost
PDF	(Adobe) Portable Document Format	UMR	Unscheduled Maintenance Ratio
PPM	Pages Per Minutes	UPnP	Universal Plug and Play
PQ	Print Quality	USB	Universal Serial Bus
PS/3	PostScript Level-3	USDR	Un-Shut Down Rate(=NSDR)
PVC	Printing Video Controller in the SPGPm(Graphic Processor for Printer)	XCMI	Samsung's Management Information Base
QCD	Quality, Cost, and Delivery	WA	Warranty Action
RCP	Remote Control Panel	W x D x H	Width x Depth x Height



## 6. Reference Information

## 6.2.2 Service Parts

ACRONYM	EXPLANATION
ELA HOU-SCANNER ASS'Y	ELA=Electrical Assembly, HOU =Housing
MEA UNIT-COVER PA EXIT ASS'Y	MEA= Mechanical Assembly, PA=Paper
PMO-TRAY EXTENTION MP NE	PMO= Processing Mold MP=Multi-Purpose(Bypass) tray NE=for NEC (common as Samsung Halk printer)
MEC-CASSETTE ASS'Y(LETTER)	MEC = Mechanic Combined unit
COVER-M-FRONT	M=Mold
MPR-NAME/PLATE	MPR= Machinery Press,
UNIT-LSU	LSU =Laser Scanning Unit
SMPS-SMPS(V1)+HVPS	SMPS =Switching Mode Power Supply HVPS =High Voltage Power Supply
ELA-OPC UNIT SET	OPC=Organic Photo-Conductive
ELA HOU-MP ASS'Y	MP =Multi-Purpose (Bypass) tray
PBA MAIN-MAIN	PBA =Printed circuit Board Assembly
PMO-CONNECT PAPER MFP	MFP =Multi-Functional Peripheral
FAN-DC	DC =Direct Current
CBF POWER STITCH GRAY	CBF= Cable Form
MEA UNIT GUIDE CST PA ASS'Y	CST=Cassette(Paper tray), PA=Paper
PBA LIU	PBA =Printed circuit Board Assembly LIU =Line Interface Unit for FAX
SHIELD-P_MAIN LOWER	P=Press
CBF HARNESS-LIU GND	LIU =Line Interface Unit for FAX GND= Ground
PMO-COVER FEED AY	AY=Assembly
PMO-COVER BRKT MOTER	BRKT=Bracket
CBF HARNESS-LSU	LSU =Laser Scanning Unit
IPR-SHIELD SMPS UPPER	IPR=Iron Press
PMO-BUSHING P/U.MP	P/U=Pickup MP=Multi-Purpose (Bypass) Tray
PMO-HOLDER GEAR TRr	TR= Transfer Roller
SPRING ETC-TR_L	TR_L=Transfer Roller - Left
PMO-CAM JAM REMOVE	PMO-CAM= Processing Mold-CAM
PMO-LOCKER DEVE	DEVE=Developer

## 6. Reference Information

ACRONYM	EXPLANATION
SPECIAL SCREW(PANNEL MFP)	MFP =Multi-Functional Peripheral
A/S MATERAL-DUMMY UPPER ASS'Y	A/S=After-Service
MCT-GLASS ADF	MCT= Machinery Cutting ADF=Automatic Document Feeder
PPR-REGISTRATION EDGE(F)	PPR= Processing Press
IPR-HOLDER GLASSI	PR=Iron Press
MCT-GLASS SCANNER(LEGAL)	MCT= Machinery Cutting
CBF HARNESS-OPE	OPE=Operation Panel(Control Panel)
PBA SUB-D_SUB	PBA SUB-D_SUB =>Sub Printed circuit Board Assembly for the D-SUB type electrical connector (D-Sub) a kind of the connector type(shape 'D')
COVER-M-CCD CABLE	M=Mold CCD=Charge Coupled Device
COVER-SCAN LOWER(UMAX)	UMAX=> Supplier's name for CCD module
ICT-INSERT SHAFTI	ICT= Iron Cutting
IPR-BRK SCAN BD	IPR=Iron Press BRK=Bracket BD= Board
CBF SIGNAL-CCD FFC	CCD = Charge Coupled Device FFC =Flexible Flat Cable
COVER-M-OPE	M=Mold OPE=Operation Panel(Control Panel)
KEY-M-COPY	M=Mold
PLATE-M-ALPHA KEY	M=Molde ALPHA=Alphabet
PMO-GUIDE DP SIDE	DP=Duplex
RING-CS	CS= Compress
GEAR-MP/DUP DRV	MP =Multi-Purpose (Bypass) tray DUP DRV = Duplex Driver
IPR-BRKT G DUPI	PR=Iron Press BRKT=BRACKET G= Ground UP=Duplex
PMO-BUSHING TX(B4)	TX=Transmit
PMO-TRAY CASE, MP	MP=Multi-Purpose tray(Bypass tray)

## 6. Reference Information

ACRONYM	EXPLANATION
SPRING CS RE	CS=Compress RE=Rear
SPRING CS FR	CS=Compress FR=Front
PMO-BUSHING FINGER, F	F=Front
ICT-SHAFT-EXIT LOWER ID	ID=Idler
SPRING-EXIT ROLL FD	FD=Face Down
PMO-BUSHING_P/U,MP	P/U=Pickup MP =Multi-Purpose (Bypass) tray
PMO-HOLDER CAM MPF	MPF=Multi-Purpose Feeder(=MP)
PMO-GEAR P/U MPF	P/U=Pickup
MFP =Multi-Functional Peripheral	
RPR-RUBBER PICK UP,MP	RPR=Rubber Press
PBA SUB-MP SEN	PBA SUB-MP-SEN =>Sub Printed circuit Board Assembly for the MP-SEN(= Multi-Purpose (Bypass) tray-Sensor)
A/S MATERIAL-PICKUP,MP	
FOOT-ML80	
HOLDER CATCH CST MC2	MC2=>McKinley2 (Samsung Project code name)
IPR-GROUND PLATE A(OPC)	OPC=Organic Photo-Conductive
ELA M/M-AUD SPEAKER	ELA M/M => Electrical Assembly M/M AUD=Audio
CBF HARNESS-OPC GND	OPC GNG=Organic Photo-Conductive-Ground
IPR-GROUND PLATE SCF	SCF=Second Cassette Feeder(Tray2)
PBA SUB-PTL	PBA SUB-PTL=>Sub Printed circuit Board Assembly for the PTL(= Pre Transfer Lamp)
PBA SUB-FEED+P.EMP SEN.	PBA SUB-FEED=>Sub Printed circuit Board Assembly for the feeder EMP SEN=Empty Sensor
MOTOR STEP-MCK2(MAIN)	
GEAR-EXIT/U	EXIT/U=EXIT/Upper
GEAR-RDCN FEED INNER	RDCN=Reduction
CBF-HARNESS-MAIN-THV WIRE	THV =Transfer High Voltage
CBF-HARNESS-MAIN-MHV WIRE	MHV= High Voltage(Charge Voltage)

## 6. Reference Information


ACRONYM	EXPLANATION
GEAR-EXIT/U,ID	U=Upper ID=Idler
IPR-TERMINAL FU	FU=Fuser
PMO-BEARING H/R-F	H/R-F=Heat Roller - Front
BEARING-H/R L	H/R-L=Heat Roller -Left
PEX-ROLLER EXIT F_UP	PEX= Processing Extrude F_UP=Face Up
SPRING ETC-P/R	P/R=Pressure Roller
SPRING(R)-CAU-HOT-FU	CAU-HOT-FU = Caution Hot -Fuser
PMO-ARM ACTUATOR	PMO-ARM= Processing Mold Arm
LABEL(R)-HV FUSER	HV=High Voltage (220V)
LABEL(R)-LV FUSER	LV=Low Voltage (110V)
PPR-SPONG SHEET	PPR=Plastic Press
IPR-P_PINCH(SCAN)I	PR-P = Iron Press
ROLLER-REGI	REGI=Registration
PBA SUB-REGI	PBA SUB-REGI => Sub Printed circuit Board Assembly for the Registration
GROUND-P_SCAN ROLLER	GROUND-P =Ground-Press
IPR-GUARD C/O S/W	C/O = Cover Open S/W= Switch
MEA UNIT-TX STACKER	TX =Transmit
IPR-WASHER SPRING CU	CU=Curve

## 6.3 The Sample Pattern for the Test

The sample pattern shown in below is the standard pattern used in the factory.  
The life of the toner cartridge and the printing speed are measured using the pattern shown below.  
(The image is 70% of the actual A4 size).

### 6.3.1 A4 ISO 19752 Standard Pattern

This test page is reproduced at 70% of the normal A4 size



## 6.4 Selecting a location

Select a level, stable place with adequate space for air circulation. Allow extra space for opening covers and trays.

The area should be well-ventilated and away from direct sunlight or sources of heat, cold, and humidity. Do not set the machine close to the edge of your desk or table.

### Clearance space

- Front: 482.6 mm (enough space so that the paper tray can be removed)
- Back: 180 mm (enough space for ventilation)
- Right: 100 mm (enough space for ventilation)
- Left: 100 mm (enough space for ventilation)

